



SRM

STEPP Recycler Mixer



OPERATIONS/MAINTENANCE/PARTS MANUAL Diesel Burner Systems



Warranty

Stepp Manufacturing Company Inc. hereby warrants to the original purchaser that products manufactured by Stepp Mfg. will be free from defects in material and workmanship for a period of one (1) year from the date of purchase.

Stepp Mfg., at its discretion, will provide for the repair or replacement of any part found upon examination by Stepp Mfg. to be defective, except as noted below. Such repair or replacement will be free of charge to the original purchaser for a period of one (1) year from the date of purchase, except as noted below.

No warranty is extended to cover:

- Product pump wear or damage caused by foreign objects.
- Routine maintenance, cleaning, and adjustments.
- Parts/components that have been altered, misused, or improperly adjusted or maintained.
- Transportation to and from the place of warranty repair.
- Removal of material from equipment.

The following items are covered solely by their manufactures warranty:

- Engines
- Hydraulic components
- Burners
- Pumps
- Tires
- Other component parts

The following items are covered by a pro-rata warranty:

- Hoses that carry heated materials.
- Heating elements for hoses and wands.

Disclaimer of further warranty:

Stepp Mfg. makes no warranty, expressed or implied, other than this warranty. The implied warranties of merchantability and fitness for particular purpose are hereby disclaimed. Repair or replacement of products or parts proving to be defective in material or workmanship shall be the exclusive remedy for breach of this warranty.

Stepp Mfg shall not be liable for incidental or consequential damages including but not limited to: damages for inconvenience, rental or purchase of replacement equipment, for loss of profits, loss of material, or other loss resulting from breach of this warranty.

Stepp Mfg reserves the right to incorporate any changes in design into its products without obligation to make such changes on products previously manufactured.

Please see Warranty section for more details.

Stepp Manufacturing Co., Inc.
12325 River Road
North Branch, MN 55056
P: 651-674-4491 F: 651-674-4221
www.steppmfg.com

INTRODUCTION

SRM Recycler

Thank you for selecting *Stepp* highway maintenance equipment. We are confident you will be satisfied with the *Stepp Recycler Mixer*. *Stepp Manufacturing* is backed by over 70 years of experience in the design and manufacture of highway maintenance equipment. This experience, along with our innovative design and unique features, make the *Stepp Recycler Mixer* an indispensable piece of equipment for your road repairs.

In order to assure safe operation of this equipment, the operator must read and understand all operating procedures and safety notices contained in this manual. In addition, the operator *must* receive instruction on how to safely operate the *Stepp Recycler Mixer*. Contact the manufacturer if any questions arise or if you desire training for additional staff members.

Operating instructions, adjustments, and periodic maintenance procedures are given so you, the operator, can keep your unit working like new and expect many years of dependable service from it. Remember, any machine, regardless of design or type, will perform only in relation to the way it is operated and the maintenance it receives.

Read this manual carefully and observe all warnings and cautions. If you have any recommendations or comments regarding this manual, please send them to: Stepp Manufacturing Co. Inc., 12325 River Road, North Branch MN 55056-6225 or call 651-674-4491. All comments we receive are reviewed and may be incorporated into future manuals.

When ordering parts or making any inquiry about the *Stepp Recycler Mixer*, be sure to include the model and serial number found on the data plate attached to the frame.

WARNING *Do not use the equipment unless the operator has read and understood the operating and safety instructions and has received proper training. Do not operate equipment unless all guards and safety devices are in place and functional.*

WARNING *Do not exceed safe operating temperature of asphalt or bituminous material. Know the "Flash Point" temperature of the material being used and DO NOT exceed this temperature. The recommended operating temperature information is available from the material manufacturer. Exceeding the recommended temperature may cause equipment damage and serious injury or death.*

Dimensions (approx.)

Length.....234 in.
Width.....99 in.
Height.....Operating 116 in.
Weight.....5,350 lbs.

General

Fuel Tank Capacity..... 60 Gallons

Preheat Hopper

Capacity.....10 cu.ft.
Opening Dimensions.....23"x 38"

Loading Conveyor

Belt..... 16" Wide Cleated
Hydraulic Motor.....4.0 cu.in. Hydraulic Motor w\ Forward-Reverse

Mixing Chamber

Chamber Type.....Continuous Batch Mixing
Mixing Style..... Rotating Pugmill
Liner Type.....U-shaped, Replaceable
Combustion Chamber Liner Material.....Replaceable ¼" Wear Resistant AR Steel
Insulation Type and Thickness..... 2" Fiberglass & Cerwool, 2" thick
Pugmill Drive, Hyd Motor.....5.75:1 Gear Reduction Driven by ¹⁸/₉ ci 2 speed

Pugmill:

Pugmill Dimensions.....Length 57" x Diameter 27"
Shaft Size.....2½" Square
Paddle Size..... Replaceable 4" x 5"
Paddle Material..... Reversible, Replaceable, ¼" Wear Resistant AR Steel
Number of Paddles.....24

Mixing Chamber Heating System

Burner Type Indirect Diesel, Forced Air
Number of Burners.....Two (2)
Fuel Type..... Diesel
Manufacturer.....Beckett®
BTU Output.....up to 420,000 BTU each - 840,000 BTU Total

CONTINUED ON NEXT PAGE

Kettle Pumping System

Pump Model.....	Viking HL32®
Relief Valve	WPC Valve
GPM Output Rating.....	20 gpm
Pump Mounting.....	Submerged
Pump Drive.....	Hydraulic, Reversible, Variable Speed with PLC Display

Engine

Manufacture.....	Kubota®
Model.....	V1505EB
Displacement.....	81 cubic inch
Number of Cylinders.....	(4)
Horse Power.....	35.1 HP
Fuel Type.....	Diesel
Cooling.....	Liquid

Hydraulic System

System Type.....	Eaton 7000 Series Load Sensing
Pump Displacement.....	Variable 0 to 1.9 cu.in.
Control type	Forward/Reverse Flow Control, Electric Over Manual Operated, Expandable Manifold Cartridge Valve Hydraulically Powered Hopper Agitator, Hopper Loading Doors, Sub. Pumping System, and Loading Conveyor
Reservoir Capacity.....	30 Gallons
Filtration.....	10 Microns

Chassis

Number of Axles.....	Two (2)
Axle Capacity.....	6000 lbs. each
Tire Size.....	225/75R15
Brake Type.....	Electric Std (Hyd Optional), all 4 wheels
Landing Gear Static Capacity.....	8,000 lbs each
Screw jack Quantity.....	One (1)
Hitch Type.....	3" Pintle Ring or 2 5/16" Ball Type adjustable from 24" to 31"
Frame Material.....	2"x 6"x 3/16" Rectangular Tubing
Lighting.....	Approved w/ Breakaway Kit
Recessed Grommeted Lights.....	Standard

TABLE OF CONTENTS

Introduction	3
Warnings, Cautions, Notes	7
Operations	9
Maintenance	27
Trouble Shooting	37
Replacement Parts	45
Warranty Guide	101
Schematics	107
Hydraulic Oil MSDS	111
Tire Information	Insert
Engine Manual	Insert

IMPORTANT NOTICE!

This manual contains cautions and warnings that alert you to potential safety issues.

WARNING is used to inform you of conditions or operations that could cause serious injury or death.

CAUTION is used to inform you of conditions or operations that could cause damage to the equipment.

NOTE is used to provide you with additional information that may be helpful or useful for a particular situation.

Before Starting or Operating this Machine

Understand and observe all the following **Warnings**, **Cautions**, and **Notes**.

WARNINGS

- ◆ This equipment contains mechanical and heating components that may cause serious injury or death if not handled or maintained properly. All personnel must be properly trained in the operation and maintenance of this equipment.
- ◆ Before refueling, shut off the burners and allow all flames in the burner and pilot light to extinguish. Shut off the engine.
- ◆ Check fuel lines, fuel line connections, and all other components for leaks. If any leaks are found, they must be repaired before using the unit.
- ◆ Know the temperature required for the material being used, and do not exceed this temperature. Avoid over heating, as this may cause equipment damage, personal injury, and/or death.
- ◆ Never load a tank with heated oil when moisture is present in the tank. Depending on the temperature of the hot oil, the moisture may instantly boil causing hot oil to foam up and out of the tank causing severe burns.
- ◆ Do not operate the tack tank burner when the amount of material in the tank is less than 4" above the flues. Allow 10 minutes cool-down time after the burner has been shut off before exposing the flues. Exposed flues will over-heat and cause an explosion and/or fire.
- ◆ The tack tank cover must be unlatched when operating the tack tank burner. This is to provide for emergency venting, in the event of a flash, to prevent the tank from exploding.

CAUTIONS

- ◆ Know the materials being used and know the proper handling, heating, application, clean-up, and storage procedures. Not all materials are compatible with each other. Many materials have a very limited shelf life. Most materials require special handling procedures to prevent personal injury and/or equipment damage. Contact your material supplier and/or manufacturer for proper handling instructions. Equipment malfunction or damage due to improper handling or use of the materials is not covered by warranty.
- ◆ Do not exceed the maximum heating temperature or storage time as recommended by the material manufacturer. This may cause emulsion type materials to separate and become difficult or impossible to remove from the machine. Consult with the material manufacturer for recommendations.
- ◆ Over-agitation or circulation may cause emulsion type materials to separate and become difficult or impossible to remove from the machine. Consult with the material manufacturer for recommendations.
- ◆ Do not mix *Anionic* and *Cationic* materials together, as the materials attach to each other and will become difficult or impossible to remove from the machine. If you are not sure consult your material supplier.

NOTES

- ◆ Become familiar with the Material Safety Data Sheet (MSDS) for the material being used in the machine and take appropriate safety precautions. Wear the proper clothing and protective gear as recommended by the MSDS and your safety director.
- ◆ DO NOT use the equipment unless it is in good condition.
- ◆ In case of skin contact with hot materials, dip into **cool, clean water immediately**. Do not wipe the product, as this will spread the burn.
- ◆ Consult the MSDS and contact your safety director for proper extinguishing of petroleum based fires.
- ◆ Carry a fire extinguisher(s) as recommended by your safety director.
- ◆ Notify your supervisor or the manufacturer if any questions arise concerning the operation of this equipment.

OPERATIONS

WARNING: *Before refueling, shut off the burners and the engine.*

CAUTION: *Be sure operators have been properly instructed in starting and operating all equipment before beginning.*

NOTE: *See following pages for specific instructions on operating burners and heating systems.*

Pre-Trip Inspection

1. Check engine fluid levels & grease machine.
2. Check tire pressure.
3. Start conveyor check for wear & tracking.
4. Inspect unit for any physical damage.
5. Check pugmill for broken paddles and excessive wear.
6. Check that discharge door is operating properly.
7. Truck hook-up and lights .

Transporting

Trailer Hook-up

1. Connect trailer to towing vehicle
 - a. Assure hitch is engaged properly.
 - b. Attach safety chains to towing vehicle.
 - c. Connect battery charging circuit to tow vehicle if required. (see illustration below)
 - d. Connect electrical plug to towing vehicle.
 - e. Connect breakaway cable to towing vehicle.
 - f. Check operation of lights and brakes.
2. Secure trailer for transport
 - a. Shut OFF the engine and burners.
 - b. Shut OFF all fuel valves.
 - c. Be sure the product temperature is not above the recommended operating temperature.
 - d. Securely latch the tank cover.

WARNING: *Prior to transporting, the driver of the tow vehicle must assure the safety of the operation. The driver must also know, and assure, that the product temperature is within limits.*

1. Start engine (refer to engine operations).
2. Turn on control box power switch.
3. Load bituminous/asphalt material into kettle using the safety loading chute. **Make sure no moisture is present in tank.** Be sure to wear proper protective clothing. Flues must be completely covered with 4" or more of material to prevent equipment damage or personal injury. Turn burner-oil switch on. The red indicator light on the switch will turn green. Set tack oil SP (set point) thermostat to desired temperature using the up and down buttons on the controller. The tack oil thermostat will display the actual temperature (top reading) and SP (set point), or desired, temperature. Depending on the asphalt materials being used, set temperature to a lower setting to allow temperature to "creep" for initial heat up.
4. When material is hot enough to flow, set valves for circulation and engage product pump in "Pump" position (refer to pumping operations chart located on the rear of the pugmill). Start the loading conveyor.
5. Fill preheat hopper with recyclable asphalt material to a level even with the top edge. Pieces must be small enough to pass through the trap doors. The equipment will provide better performance with smaller pieces. Start conveyor and load hopper with material. **NOTE:** *Check hopper doors. Doors must be closed prior to loading.*
6. Start pugmill burners, front and rear. Switch will turn green when on. **CAUTION:** *Do not use recycler timer for initial pugmill warm up. This could cause residue in hopper to catch fire. If hopper catches fire, dispense load of material into hopper to smother fire, turn the burners off, and allow the machine to cool down before re-firing. Burners will shut off at set point temperature (250 °). Over heating may cause pugmill damage.*
7. Start pugmill mix paddles (2). **NOTE:** *Make sure pugmill paddles are moving freely in both directions, forward and reverse positions.*
8. Engage pugmill mix. Empty contents of the preheat hopper into the recycler mixing chamber using the hydraulic operated trap doors using the door open switch.
9. Set the recycler burner timer for desired heating time by using the up and down buttons next to the timer. The amount of mixing time and heat necessary will be determined through experience. Moisture and material quality varies and will vary the timer setting.
10. Set batch time. **NOTE:** *Set initial batch time for 10 minutes. Normal batch times may vary from anywhere between 8-16 minutes, with the first batch of the day taking longer due to heating the machine up.* Press the "Cycle Start" button to start the batch timer and activate the burners to the pugmill set point. If more time is needed, adjust time accordingly. Operator will need to dispense a small amount of material to test the temperature with a hand held infrared scanner. Burners will fire to the high level set point until additional time has elapsed. When burners are firing, watch the top stack for moisture dissipating. Batch will be very close to temperature once the steam has stopped and you are getting a clean exhaust. If exhaust starts to smoke or turn blue, the material is overheated or very close to being overheated. If blue smoke is present turn burner switches off and discharge material. **CAUTION:** *Discharge material at 320-350°. If material is at temperature before time is done, shut off the burner.*
11. Adjust the damper on the exhaust stack according to heating needs. Closing the damper will retain more heat in the recycler's mixing chamber. Opening the damper will allow raw aggregate to dry quicker.

12. If necessary, add heated bituminous binding material to the recycler mixing chamber (refer to the plumbing operations chart). Here again, experience is the best indicator of how much to add. Start with $1\frac{1}{2}$ - $1\frac{1}{2}$ gallons of oil. Know the material being added and the flash point. We recommend that you use an AC type oil and add the oil in the first three minutes of the batch timer. The pump has an oil counter so you can meter the amount of material added. With the pump running in the “forward” position, move valve #2 to the “Mixer” position. The pump will run until the pre-set amount is reached. At that point, the pump will stop and the attention light will flash until valve #3 is returned to “Recirculate” position.



13. Reload preheat hopper while you wait for the mixing action to be completed. This will allow for the next batch to be preheated, resulting in faster batch times.

14. Set the toggle switch to discharge in order to empty the mixed material onto the shovel platform for easy shoveling. Swinging the shovel platform up out of the way will allow the mixed material to empty directly on the ground. The switch has two settings: green for slow discharge, yellow for higher speed discharge. To engage high speed, press discharge twice.

15. Reload the next batch. Press “Cycle Start” button in order to start the next batch.

16. To shut down the machine shut off all burner switches. Empty the recycler mixing chamber.

WARNING: All flames (burners and pilot lights) must be extinguished before flushing operations begin to reduce the chance of fire and/or personal injury.

17. Flush the pump, wand, and plumbing to prevent a plugged system (refer to the plumbing operations chart). **NOTE:** Running a load of coarse rock through the unit will help remove asphalt deposits.

18. Shut off the engine.

NOTES:

- Operator must have infrared heat gun to operate machine.
- Check “Set Points” on control panel.
- Never have burners on without material in pugmill, unless you are doing start up.
- Check material temperature at 8 minutes. Material temperatures will climb quickly once moisture is out of material. Check every minute or two after that.
- Normal batch times vary from 6-18 minutes depending on moisture and material quality.
- Initial batch could take 2x’s longer, due to initial heat up of machine.
- $1\frac{1}{2}$ - $1\frac{1}{2}$ gallons of oil additive is average for material.
- Allow cooling at end of the day. (Open hopper doors and run pugmill for 10 minutes in discharge.)

Helpful Tips to Making Quality Recycled Materials

1. **Have your millings tested for asphalt content.** This will help you decide how much additive you need. The average ton of asphalt top mix has 5-7% oil by weight. This translates into 100-125 pounds of asphalt added to virgin aggregate to make top mix. PG grade asphalts are approximately 7.5 pounds per gallon. So if you convert that to gallons there is approx. 13.3 gallons of asphalt in 100 pounds to make 1 ton of mix. $100/7.5 = 13.3333$. Most millings need 1/2-1% of new oil to give you a quality patch material. The SRM makes approximately a 1000 pound batch, so on average you need to add 1/2 gallon to 1 1/2 gallon or 3.75 pounds to 11.25 pounds of asphalt additive to make a quality mix.
2. **Recycled materials have huge variables.** Different asphalt contents, different moisture contents, different aggregates, base material containments, and different size aggregates will all vary the batch times and material quality. Making your first batches in your SRM will take some experimenting. You will need to find the right recipe. Start with shorter batch times and check your material often on the first batch or two. Start with a little oil and add more as you need it. Once you come up with your recipe for the materials that you are using you should see consistent results. The next batches will be very similar and you should only have to make minor adjustments.
3. **Keep materials dry.** Moisture content is the number one cause for slow batch times. If you can, keep your millings inside or covered. It takes more BTU to dissipate a gallon of water than it does to melt a gallon of asphalt. Moisture acts as a refractory in the material and can not be dispersed until turned to a gas (steam). High moisture content can double or triple batch times, so having dry millings is key to higher production.
4. **Quality of materials.** Using quality materials also aids in faster batch times. Materials with large aggregates take longer to drive the heat into the stone. Contaminated materials with base also take longer to heat because of lack of oil in the materials. Materials with higher asphalt contents also heat up faster. The SRM does not care, it just may affect the heat up times.
5. **The SRM is capable of making materials from virgin aggregates.** You can make virgin materials with the SRM, you just need more oil. Using the reference above, in #1, you can make your own custom mixes. Sand mixes, fine mixes, and mixes from virgin materials. Again, you will need to do some experimenting to get the right mix design. If making virgin mix, use the 5-7% to get you started (5-7gallons). Always start with a smaller amount of oil; you can always add more oil, but you can't take it away. Different oils will also give you different results in materials.
6. **Pre-made cold mix materials.** You can use your SRM to warm your cold mix materials. Use extreme caution when doing so. Most cold patch materials have a high content of cutter (solvent) in the oil. This makes the material soft and pliable, but also makes them very easy to catch on fire. If you are using the SRM to heat cold patch material, only fire the burner in 1-2 minute cycles and check the temperature very often to prevent the material from flashing.

WARNING: *The burners must be shut off when the product reaches a level approximately 4" above the flues. Exposed flues will overheat causing an explosion in the tank. This will cause equipment damage and possible injury or death to personnel.*

Before Igniting the Burner:

1. Know the materials being used. DO NOT exceed flash point or operating range temperatures.
2. Ensure the kettle is level and the heating flues are completely immersed in product to prevent damage to equipment or personal injury.
3. The kettle cover must be unlatched to provide emergency venting in event of a flash.
4. Vent the kettle by opening the cover for five minutes prior to firing.
5. Load bituminous/asphalt material into kettle using the safety loading chute. **CAUTION:** *Make sure that no moisture is present in tank and make sure to wear proper protective clothing.* Turn "burner-oil" switch on. When material is hot enough to flow, set valves for circulation and engage product pump in "Pump" position (refer to pumping operations chart located on the rear of the pugmill).

WARNING: *Failure to observe these instructions may cause damage to the equipment, personnel injury, or death.*

Igniting the Burner:

1. Verify heating flues are completely covered with a minimum 4" of product.
2. Verify proper heating temperature, and set the SP (set point) thermostat to that temperature.
3. Turn oil burner power switch ON and burner will ignite; a small flame indicator will appear. The red indicator light on the switch will turn green. Set "tack oil SP" (set point) thermostat to desired temperature using the up and down buttons on the controller. Tack oil thermostat will display actual temperature (top reading) and SP (set point), or desired, temperature. Depending on asphalt materials used, set temperature to a lower setting to allow temperature to "creep" for initial heat up.
4. Monitor product level in kettle and shut burner OFF when oil level is 4" above heating flues.

NOTE: *If the "Lockout" message appears on the screen, it indicates a malfunction of the burner. Verify fuel supply to the burner (proper fuel and no air bubbles in system) then reset the burner by setting power switch OFF then ON. If problem persists, consult a service technician. DO NOT reset burner more than two times, as excess fuel may accumulate in combustion chamber creating a fire hazard.*

Shutting off the Burner:

1. Set thermostat to the lowest setting and allow a one minute cooling period.
2. Turn OFF burner oil switch on the control box.
3. Close and latch kettle cover.
4. Turn main power switch OFF.

WARNING: *It is the operators responsibility to set the proper temperature on the thermostats as required for the operation.*

Before Igniting the Burner:

1. Know the materials being used. DO NOT exceed flash point or operating range temperatures.

Igniting the Burner:

1. The SRM recycler chamber has two set point temperatures. One “higher firing” set point for heating up the mix, and one “stand-by” temperature setting that keeps the liner and materials at a given temperature. Pressing the “Cycle Start” button changes the max set point to the “higher firing” set point. These set points are set at 750°F for the “higher firing” set point, and 250°F for the “stand-by” set point. Both of these are adjustable from the set-up screen, which is accessed by pressing the ADJUST MILL SET POINT button located on the upper right hand of the display. The temperatures displayed on the screen are the temperature readings of the pugmill liner, not the material temperature.
2. Turn ON front, rear, or both recycler burner power switch(s) as desired and burner(s) will ignite and a flame indicator will appear next to the front or rear on the recycler chamber display. The burner will fire until the standby temperature is reached. The switch will turn green when on. **CAUTION:** *Do not use recycler timer for initial pugmill warm up. This could cause residue in hopper to catch fire. If hopper catches fire, dispense load of material into hopper to smother fire, turn the burners off, and allow the machine to cool down before re-firing. Burner's will shut off at set point temperature (250 °). Overheating may cause pugmill damage.*
3. Set batch time. **NOTE:** *Set initial batch time for 10 minutes. Normal batch times may vary from anywhere between 8-16 minutes, with the first batch of the day taking longer due to heating the machine up.* Press the “Cycle Start” button to start the batch timer and activate the burners to the pugmill set point. If more time is needed, adjust time accordingly. Operator will need to dispense a small amount of material to test the temperature with a hand held infrared scanner. Burners will fire to the high level set point until additional time has elapsed. When burners are firing, watch the top stack for moisture dissipating. Batch will be very close to temperature once the steam has stopped and you are getting a clean exhaust. If exhaust starts to smoke or turn blue, the material is overheated or very close to being overheated. If blue smoke is present turn burner switches off and discharge material. **CAUTION:** *Discharge material at 320-350°. If material is at temperature before time is done, shut off the burner.*

NOTE: *If the "Lockout" message appears on the screen, it indicates a malfunction of the burner. Verify fuel supply to the burner (proper fuel and no air bubbles in system) then reset the burner by setting power switch OFF then ON. If problem persists consult a service technician. Do not reset burner more than 2 times as excess fuel may accumulate in combustion chamber creating a fire hazard.*

Shutting off the Burner:

1. Turn OFF power switch(s) on the control box.

OPERATIONS

PLC Controller

Tack Oil: Shows SP (set point) and actual temperature of oil kettle.

Recycler Chamber: Shows temperature of the recycler/mixing chamber. Does not show indicated material temperature.

Tack Oil SP (set point) Temperature Adjustment


Oil Pumped SP (set point) Gallon Adjustment

Meter Reset: Resets the oil pumped to zero

Valve Position: Refers to #3 recirc/mixer valve located above control box.

Cycle Start: Resets the batch timer.

Burner Timer Adjustment: Top display batch time will not restart without pressing the cycle start button.



Oil Pumped: Displays actual gallons pumped and SP (set point), or desired, not restart without pressing the cycle start button. 1/10 gallon increments.

Burner Timer: Top display batch time will not restart without pressing the cycle start button

All PLC Switching are latching switches. Press once to turn on and press second time to turn off. When switch is activated it will turn from red to green.

Conveyor Forward/Reverse

Oil Pump Forward

Pugmill Mix: Press once for activating mixer. Indicator will turn green when on.

Pugmill Discharge: Press once for discharge and twice for high speed discharge.

Top Door Open/Close: Opens trap door

Burner Controls: Turns on oil burner, front and rear pugmill burners.

The physical panel has two rows of switches. The top row includes: PUGMILL MIX OFF, OIL PUMP FOR OFF, CONVEYOR FOR OFF, DOOR OPEN, and COMPACT CARRIER UP. The bottom row includes: PUG DISCH HIGH/LOW OFF, OIL PUMP REV OFF, CONVEYOR REV OFF, DOOR CLOSE, and COMPACT CARRIER DN. The right side has: BURNER OIL ON/OFF, PUGMILL BURNER FRONT ON/OFF, and PUGMILL BURNER REAR ON/OFF. Below these are STROBE ON/OFF and WASH DOWN ON/OFF.

Oil Pump Reverse

Compactor Plate Carrier up/down

Optional Equipment

OPERATIONS

Engine Starting

WARNING: *Be sure all pre-start checks are complete prior to starting engine.*

The SRM is equipped with a digital engine management system. This system will shut the engine down in case of an engine overheat or low oil pressure. It is also equipped with an hour meter, cold weather glow plug button, and a starting button.


1. Fill fuel tank.
2. Turn "Key Switch" clockwise to the "Start" position.
3. Press and hold Yellow glow plug button for 30-90 seconds.
4. Press Green button to start.
5. If engine does not start on first try, you must turn the "Key Switch" OFF and restart the starting sequence.
6. To shut engine down turn "Key Switch" counterclockwise.

NOTE: *If engine will not turn over, check the emergency shutdown button located on the operators control box.*



T10009431

ASPHALT RECYCLER HOT OIL OP CHART



OPERATION	Valve 1	Valve 2	Valve 3	Valve 4	Valve 5	Pump Switch
Recirculate Back to Tank	Mixer	Oil Tank	Recirc	Product	Recirc	Forward
Pump Wand	Wand	Oil Tank	Recirc	Product	Wand WPC	Forward
Pump to Mixer	Mixer	Oil Tank	Mixer	Product	Recirc	Forward
Suckback Mixer Plumbing	Mixer	Oil Tank	Recirc/Mixer	Product	Recirc	Reverse
Suckback Wand	Wand	Oil Tank	Recirc	Product	Wand	Reverse
Flush Plumbing	Mixer	Flush	Recirc	Flush	Recirc	Forward
Flush Wand	Wand	Flush	Recirc	Flush	Wand	Forward

WARNING!!

DO NOT allow flushing solvent to enter the hot oil tank or mixer.
DO NOT allow the hot oil tank burner to operate with the product level less than 2 inches above the flues. Severe damage to equipment and possible serious injury will result.

WPC - Wand Pressure Control Valve

WARNING:

DO NOT allow flushing solvent to enter hot oil tank or mixer.

DO NOT allow the hot oil tank burner to operate with the product level less than 2 inches above the flues. Severe damage to equipment and possible serious injury will result!

DO NOT flush through a heated wand.

HOT OIL PUMPING SYSTEM 10-120 RECYCLER		
<p>Valve V1: Mixer / Wand Valve V2: Flush / Oil Tank (Recirculate) Valve V3: Mixer / Recirc (Recirculate) Valve V4: Product / Flush Valve V5: Wand / Recirc (Recirculate)</p> <p>Mixer: This is the recycler mixing chamber, where asphalt is heated/mixed and product is added. Wand: This is the spray wand from which tack coat can be sprayed. Flush: This refers to the solvent tank where solvent is kept to clean out the hoses. Recirc: This refers to the recirculated material within the system. Product: This refers to the kettle tank or Product in the kettle tank where the tack coat is melted.</p> <p>Valve Positions Required for Various Valve Functions:</p> <p>WARNING: Before adjusting valves, shut off the pump to the neutral position.</p> <p>1) Pump Wand: Move liquid from Product tank to spray wand. A) V1 - Wand B) V2 - Oil Tank C) V3 - Recirc D) V4 - Product E) V5 - Wand / WPC (Wand Pressure Control) j) WARNING!!! When wand is shutoff, DO NOT move valve V5 fully to Wand. Doing so will cause excessive pressure build up, causing a loud high pitch tone from the hydraulic system, risking hose rupture and high pressure at the spray wand head. ii) Move valve V5 toward Recirc to reduce spray pressure. This will control the pressure of the Product being sprayed. F) Control Panel: Set 'Hot Oil' switch to 'Forward'</p>	<p>2) Pump/Product to Mixer: Pump Product from Product Tank to Mixer. A) V1 - Mixer B) V2 - Oil Tank C) V3 - Mixer: Adjusting this valve to Mixer Directs flows to Mixer. Adjusting this valve to Recirc directs flow away from Mixer. D) Control Panel: Turn 'Hot Oil' switch to 'Neutral' E) Control Panel: Push RST (Reset Button) on the Red Lion Controller, which sets counter to 0 (Zero) F) Control Panel: Turn 'Hot Oil' switch to 'Forward' G) Control Panel: The Red Lion Controller will show you how much product is being added to the Mixer. i) When the desired amount of product has entered Mixer, turn V3 to Recirc to stop product flow to the mixing chamber and return product to the tank H) V4 - Product I) V5 - Recirc</p> <p>3) Recirculate Back to Tank: Circulate product through plumbing to prevent Product build up in plumbing lines. A) V1 - Mixer B) V2 - Oil Tank C) V3 - Recirc D) V4 - Product E) V5 - Recirc F) Control Panel: Set 'Hot Oil' switch to 'Forward' SYSTEM CLEANOUT PROCEDURES</p> <p>4) Suckback Wand A) V1 - Wand B) V2 - Oil Tank C) V3 - Recirc D) V4 - Product E) V5 - Wand F) Control Panel: Set 'Hot Oil' switch to 'Reverse' G) WARNING: Emptying lines of Product must be done before flushing system with solvent.</p>	<p>5) Suckback Mixer Plumbing: A) V1 - Mixer B) V2 - Oil Tank C) V3 - Recirc D) V4 - Product E) V5 - Recirc F) Control Panel: Set 'Hot Oil' switch to 'Reverse' G) WARNING: Emptying lines of Product must be done before flushing system with solvent WARNING: Emptying lines of Product must be done before flushing system with solvent 6) Flush Plumbing A) Set valves before starting pump. B) V1 - Mixer C) V2 - Flush D) V3 - Recirc i) WARNING: Never turn V3 to Mixer when flushing as this will direct solvent flow to Mixer and may cause a fire or explosion. E) V4 - Flush F) V5 - Recirc G) Control Panel: Set 'Hot Oil' switch to 'Forward' H) Circulate flush solvent through plumbing: Flush and circulate solvent through plumbing. 7) Flush Wand A) Set valves before starting pump. B) V1 - Wand C) V2 - Flush D) V3 - Recirc E) V4 - Flush F) V5 - Wand G) Control Panel: Set 'Hot Oil' switch to 'Forward' H) Circulate flush solvent through wand: Flush and circulate solvent through wand.</p>

T10009432

Hand Wand

Wand Pressure Control Valve (WPC Valve)

Operators must understand the proper operation of the WPC valve located on the top rear of the unit. The purpose of this valve is to direct the flow of product either back to the tank (during start-up to assist melting) or to the wand (during crack filling or pothole spraying operations).

Because of the properties of asphalt, no automatic relief valve is installed in the system. Therefore, the operator must adjust the WPC valve to a position midway between the valve stops. This will allow product to flow to the wand and also back to the tank at the same time, preventing excessive pressure from building up in the hose and wand.

Positioning of the WPC valve towards "Recirculate" will cause less flow and less pressure to the wand. Positioning of the WPC valve towards "Wand" will cause more flow and more pressure to the wand.

The WPC valve should never be positioned fully to the "Wand" position, unless the wand control valve located on the wand is fully open, or for flushing operations to ensure that flush solvent will not enter the tank. Excess flow and pressure to the wand may cause damage to the hose and system, and possibly result in personal injury.

Observing unusual flexing in the wand hose should alert the operator that excess pressure is being applied to the wand hose. Considering factors such as temperature of product, desired amount of flow and varied operating conditions will assist the operator in selecting the proper position of the WPC valve. The WPC valve must be left in the "Recirculate" position when the unit is shut down.



CAUTION: *The WPC valve should never be positioned fully to the "Wand" position, unless the wand control valve located on the wand is fully open, or for flushing operations to ensure that flush solvent will not enter the tank. Excess flow and pressure to the wand may cause damage to the hose and system, and possibly result in personal injury.*

Heated Hose & Wand (optional)

The application hose and wand are equipped with internal heating elements. The elements are powered by the 24 volt alternator run by the engine. This heating element prevents the product from freezing in the hose and wand. The electric wand heat control should be turned on 20 to 30 minutes before trying to pump material through the hose and wand. This will allow time for the material to re-liquefy in the hose.

It is recommended that you circulate the product back to the tank through the wand circulating flange provided in the hood. This is to assure proper flow and temperature of the material going through the wand. Depending upon the volume of the material going through the wand and the outside temperature, it may not be necessary to run the heated wand all the time. Once flow is established through the wand and circulating back to tank, it is recommended that the electric heating element be used only as required to maintain flow. This will help to extend the life of the heating elements. If the flow is not adequate to maintain temperature in the hose and wand, freeze up may occur. If this happens, simply turn the electric heating element on, and allow time for the material to re-melt. No clean up is required with the electric wand; just shut the machine off as the product can be re-melted by activating the *Wand Heat Control*. No additional flushing is required.

CAUTION: *Do not activate the Electric Wand Heat unless the hose and wand have product in them. Absence of product will cause the element to overheat and destroy the hose, possibly causing serious injury.*


Overnight Heater (optional)

This feature will decrease start up time by maintaining the product from 150° to 200° F, depending on ambient temperature. The system consists of a heating element submerged in the product. Set the thermostat to the desired temperature and plug the heater in. The heater requires 110V, 15 AMP service. The extension cord used must be the outdoor heavy duty type, grounded, and rated for 1500 watt service.

CAUTION: *If overnight heaters are used, make sure to vent the kettle by opening the cover for five minutes before firing the diesel burner. Failure to do so may result in a FLASH of the asphalt vapors.*

NOTE: *The heater is screwed into the rear of the kettle. To install a heater, or to replace A heater, follow these steps:*

1. Be sure all the asphalt product is drained from the tank. The tank may need to be heated and then drained if it contains frozen asphalt.
2. When the unit has cooled to ambient temperature remove the heater and replace with the new heater.
3. Replace cord if needed.



Application with Twist-Valve Wand

1. Position the WPC valve midway between the wand and recirculate position.
2. Close the wand flow control valve (located on the wand handle) and remove wand from the recirculating flange.
3. Set product pump to "Pump" position, then open the wand flow control valve to apply product to the road surface.
4. Adjust the WPC valve as necessary, being careful not to over pressurize the wand and hose assembly.
5. Monitor the level in the tank and add product as necessary.

WARNING: *The Stepp SRM requires special shut down procedures that must be followed to maximize safety and equipment performance. The procedures will assure that the hose and wand always have product in them to avoid an over-heated element. (Do **Not** suck the product back out of the wand and hose assembly) No hose cleanup is necessary as the product in the hose is re-melted at the next start up with the wand and hose heating element.*

Standard Shutdown Procedures for Units With Heated Hose

1. Turn OFF the wand heat control switch.
2. Move the WPC valve to the "Recirculate" position.
3. Turn oil pump switch to reverse position for two minutes, then turn oil pump switch to off. This will draw the product out of the pump, plumbing, and WPC valve.
4. Reduce engine RPM and allow to run at idle for a minimum of two minutes.
5. Shut OFF the engine.
6. Securely latch all covers.

CAUTION: *Do not reverse the pump with the WPC valve in the "Wand" position as this would suck the product out of the wand and hose assembly. The hose and wand must contain product to absorb the heat from the heating elements to avoid equipment damage. Only reverse the pump when the WPC valve is in the "Re-circulate" position. No hose cleanup is necessary with this system.*

Standard Shut Down Procedures for Units With Non-Heated Hose

WARNING: *The Stepp SRM requires special shut down procedures that must be followed to maximize safety and equipment performance.*

CAUTION: *Set pump to OFF or neutral before adjusting valves.*

1. Turn oil pump switch to OFF position. Red indicator light will come on.
2. Move the WPC valve to the "Wand" position and open the wand handle.
3. Turn oil pump switch to reverse position for two minutes, then turn oil pump switch to OFF. This will draw the product out of the pump, wand, plumbing, and WPC valve.
4. Set valves to flush system according to the pump chart.
5. Set WPC valve to "Full Wand" position. Failure to set this in "Full Wand" position will allow flushing solvent to enter the product tank. Insert wand into the recirculating flush tank to recover flush solvent. Turn oil pump switch to "Pump/Forward" position and flush the plumbing thoroughly for 2-3 minutes.
6. Turn oil pump switch to "Neutral/Off" position.
7. Move the WPC valve to the "Wand" position and open the wand handle.
8. Turn oil pump switch to "Reverse" position for two minutes, then turn oil pump switch to OFF. This will draw the product out of the pump, wand, plumbing, and WPC valve. This will return the flush solvent to the flush tank. Operators may choose to leave the flushing solvent in the lines overnight to assure that the lines are clean. Operator must follow the suck back flush solvent before changing valves to spray asphalt or you may contaminate the product tank with flushing solvent.
9. Reduce engine RPM and allow to run at idle for a minimum of two minutes.
10. Shut OFF the engine.
11. Securely latch all covers.

NOTE: *All plumbing operations that were used must be flushed or lines will be frozen with asphalt. Refer to the pump operations chart.*


1. **It is recommended that the product be drawn down to $\frac{1}{4}$ capacity or less prior to shutdown.** This will decrease the start up time the next time the machine is used. However if you are *certain* the equipment will be used the next day (no chance of rain, etc.), leave the unit about $\frac{1}{2}$ to $\frac{3}{4}$ full, then plug in the optional overnight heaters. This will help retain heat for a faster start up the following day.
2. **Do not heat or reheat any product for a length of time more than that recommended by the product manufacture.** This is typically 16 hours or two heating cycles. Check with your product manufacture for recommendations specific to your material.
3. **The valve at the end of the wand is not heated by the heating element.** Although heat transfer from the wand will normally be enough, by inserting the wand into the recirculating flange, additional heat from the kettle will aid in heating the valve.
4. **Overnight heating elements normally should not be used for more than 48 hours.** Check the product manufacturers recommendations for the material's maximum "pot life". The overnight heater will maintain approximately 200° F after temperatures have stabilized.
5. **If the engine quits for any reason, move the WPC valve to the recirculate position, then attempt to resolve the problem and restart the engine as soon as possible.** The proper shut down procedures must be followed before the product hardens in the exterior plumbing. If the product hardens in exterior plumbing, use heat to re-liquefy the product to re-establish flow.
6. **Avoid excessive pulling, bending, and twisting of the wand hose.** This may cause the service life of the hose and heating elements to be greatly reduced.

MAINTENANCE

MAINTENANCE

Product Pump

Fig. 1



The pump used for hot oil pumping is a gear type pump. Shaft rotation will determine which port is suction and which is discharge. A look at the Fig.1 will show how the fluid will flow through the pump. As the gears come out of mesh (A), liquid is drawn into the suction port. As the gears come into mesh (B), the liquid is forced out the discharge port. Reversing the rotation reverses the flow through the pump.

NOTE: An easy way to determine which port is suction or discharge is to note the shaft rotation and remember that the fluid takes the "long way" around the pump to get from the suction port to the discharge port.

NOTE: The idler pin, which is offset on the pump head, should be positioned toward, and an equal distance, between the suction and discharge ports.

End Clearance Adjustment

The head to rotor clearances (B, in Fig.1) should be checked every 100 hours of operation or when pump performance decreases noticeably. If adjustment is necessary the pump will need to be disassembled.

1. Measure end clearance by moving pump shaft in and out, clearance should be .005" to .007"
2. Clearances are adjusted by adding or removing head gaskets (C) of various thicknesses.

NOTE: Be careful not to adjust clearances too tight as the pump may "bind" at high operating temperatures due to expansion.

Packing Adjustment

The pump shaft packing should be adjusted after the first 50 hours of operation, then every 100 hours or when leakage increases noticeably. Note: A "small" amount of leakage is required to lubricate the packing. The pump DOES NOT need to be disassembled for this adjustment.

1. Tighten the 2 packing gland nuts (A) equally, 1/4 turn at a time, to decrease excess leakage.

NOTE: A small amount of leakage is required to lubricate the packing.




Fig. 2

CAUTION: *Do not remove hose without first removing the heating element or damage to heating element will result.*

Hose Removal:

1. Remove heating element from hose (refer to heating element removal procedures).
2. Disconnect all electrical connections from hose.
3. Separate the hose from the wand at the quick coupling.
4. Remove the quick coupling from the hose and save for reuse on the new hose.
5. Unscrew the hose from the cross fitting at the end of the boom assembly.
6. Gently pull the hose off the unit, being careful not to damage the heating element.

Hose Installation:

1. Screw the hose fitting into the cross fitting at the end of the boom assembly and tighten securely.
2. Screw the quick coupling to the other end of the hose and tighten securely.
3. Reconnect all electrical connections to hose.
4. Reinstall heating element into hose, but do not reconnect electrical connector at this time.
NOTE: *The heating element will protrude about 10" from the end of the hose.*
5. Gently heat the end of the wand with a propane torch. This will soften the material in the wand for easy insertion of the protruding hose heating element (see next step).
6. Connect the hose to the wand at the quick coupling. Use gentle pressure to insert the protruding hose heating element into the wand. **CAUTION:** *Do not apply power to the hose heating element in an empty hose or damage to the hose will result.*
7. Bring material in tank up to operating temperature (refer to operating instructions).
8. Verify hose heating element is disconnected.
9. Activate wand and boom heat for 20 minutes.
10. Pump material through wand until flowing freely (refer to operating instructions).
11. Stop pump. Connect hose heating element connector. The hose is now full of material and the unit can be returned to service.

Hose Heating Element Removal:

These instructions assume the heating element is functioning properly. If the heating element does not function, refer to the instructions on the following pages.

NOTE: *If the hose is damaged, skip steps 1 through 3, activate wand heat for 15 minutes, then begin at step 4.*

1. Start the engine and the burner and allow the product to reach operating temperature. Activate wand heat switch. Begin circulation of material through the wand into the recirculating flange when temperatures permit. When product is circulating freely proceed to step two.
2. Turn OFF the electric wand heat. Then with wand valve open, and the wand pressure control valve in the "Wand" position, reverse the pump for two minutes to clear the hose, wand, and boom of material.
3. Shut OFF the burner and the engine.
4. Disconnect the hose heating element connector at the end of the boom.

NOTE: *The following steps must be accomplished with all components warm.*

5. Remove the compression fitting that holds the hose heating element at the top of the cross fitting on the end of the boom.
6. Gently pull the heating element from the cross fitting and the hose.

WARNING: *The heating element will be HOT, wear protective clothing, leather welding gloves, and safety gear.*

CAUTION: *Do not pull on the wires to remove the heating element or damage to the element may result.*

Hose Heating Element Installation:

1. Remove wand from hose at quick coupling.
2. Lay the hose out as straight as possible.
3. Install new compression fitting into cross fitting.

NOTE: *If hose DOES NOT contain material proceed with step 4. If hose CONTAINS material, replace step 4 with steps A & B listed below.*

4. Insert heating element into compression fitting and hose. About 10" of the heating element will protrude out the other end of the hose. Tighten compression fitting.
5. Insert protruding element into wand and reattach wand to hose at quick coupling. (Gently heat wand with propane torch to ease installation if needed.)
6. Reconnect all electrical connections.

CAUTION: *Do not apply power the hose heating element in an empty hose or damage to the hose will result.*

7. Bring material in tank up to operating temperature. (refer to operating instructions) and activate wand heat.
8. Pump material through wand until flowing freely. (refer to operating instructions) The hose is now full of material and the unit can be returned to service.

Steps A & B

- A. Connect one lead of the heating element to the large terminal of the 24V alternator, and the other lead to a good chassis ground. Use 10 gage (minimum) jumper wires.
- B. Start the engine, as the heating element heats, insert it into the hose. Start and stop the engine, or disconnect the jumper wires, as needed to regulate the heat of the element. Use only enough heat to soften the material and allow the element to be pushed into the hose. (About 10" of the heating element will protrude out the other end of the hose) Tighten compression fitting.

Proceed to step 5 above.

WARNING: *The heating element will be HOT; wear protective clothing, leather welding gloves, and safety gear.*

Hose Heating Element Removal and Installation:

These instructions assume the heating element is damaged and NOT functioning. If the heating element functions properly, refer to the instructions on the previous page. The element may be damaged during removal, rendering it useless.

A functioning hose heating element is slid into the hose alongside the non-functioning element. As the material in the hose is heated with the new element, the old element can be pulled from the hose.

1. Remove wand from hose at quick coupling. About 10" of the hose heating element protrudes out of the hose and into the wand. Gently heat wand with propane torch to ease separation if needed.
2. Disconnect the hose heating element connector at the end of the boom.
3. Remove the compression fitting nut that holds the hose heating element at the top of the cross fitting on the end of the boom. Then, remove the complete compression fitting.
4. Pull the element out and to the side far enough to allow a new element to be slid in alongside the old element.
5. Connect one lead of the new element to the large terminal of the 24V alternator, and the other lead to a good chassis ground. Use 10 gage (minimum) jumper wires.
6. Start the engine, as the heating element heats, insert it into the hose along side the old element. Start and stop the engine, or disconnect the jumper wires, as needed to regulate the heat of the element. Use only enough heat to soften the material and allow the element to be pushed into the hose.
7. Pull the old heating element from the cross fitting and the hose.
8. Secure new heating element in compression fitting, then reconnect electrical connector.
9. Insert protruding hose element into wand and reattach wand to hose at quick coupling. (Gently heat wand with propane torch to ease installation if needed.)

WARNING: *The heating element will be HOT, wear protective clothing, leather welding gloves, and safety gear.*

Wand or Boom Heating Element Removal and Installation:

These instructions assume the heating element is damaged and not functioning. The element may be damaged during removal rendering it useless.

A functioning heating element is slid into the wand or boom along side the non-functioning element. As the material is heated with the new element, the old element can be pulled from the wand or boom.

1. Remove wand from hose at quick coupling. About 10" of the hose heating element protrudes out the hose and into the wand. Gently heat wand with propane torch to ease separation if needed.
2. Remove the compression fitting nut that holds the heating element in the wand or boom, then remove the complete compression fitting.
3. Pull the element out and to the side far enough to allow a new element to be slid in along side the old element.
4. Connect one lead of the new element to the large terminal of the 24V alternator, and the other lead to a good chassis ground. Use 10 gage (minimum) jumper wires.
5. Start the engine, as the heating element heats, insert it along side the old element. Start and stop the engine, or disconnect the jumper wires, as needed to regulate the heat of the element. Use only enough heat to soften the material and allow the element to be pushed into the wand or boom.
6. Pull the old heating element from the wand or boom.
7. Secure new heating element in compression fitting, then reconnect electrical connector.

WARNING: *The heating element will be HOT, wear protective clothing, leather welding gloves, and safety gear.*


NOTE: *An alternate method is to remove all insulation from the wand or boom., then heat as needed with a torch to soften the material allowing removal and installation of the heating element.*

MAINTENANCE

Pugmill Mixer


The SRM has many high torque moving parts. As a weekly inspection, we suggest that the operators check for loose fittings and loose bolts. Outlined below are some that need to be checked periodically due to the torque and vibration that the unit incurs.

1. Check for tightness of the motor and gear box assembly (#1). Because of the torque required to mix the materials, this needs to be checked weekly.
2. Check grease bearing daily (#2). There is a bearing on each end of the pugmill and on each end of the conveyor.
3. Check top discharge door for proper operation (#3).
4. Visually inspect pugmill mixer blades for proper clearance and wear (#4).



The conveyor needs to be inspected daily for wear, and to make sure that the belt is tracking properly. As the belts are used, they will stretch, requiring tightening.

1. Check grease bearings daily (#1).
2. Check belt tension and tracking (#2). To adjust tracking, you must first loosen the 4 nuts on the bearing. Do not loosen too much, you need a little tension on the nuts. Loosen the jam nut on the tension bolt and tighten or loosen the bolt tensioner the direction that you need the belt to go. Re-tighten the bearing bolts and lock jam nut down. **NOTE:** *Make all adjustments with the conveyor in the off position.* Once you make the adjustments, start the conveyor to check tracking.




TROUBLESHOOTING

	<i>POSSIBLE CAUSE</i>	<i>Items to Check /Service</i>
LACK OF PERFORMANCE	Plugged Strainer Screen	Service strainer screen
	Hydraulic Filter Plugged	Replace hydraulic oil filter
	Collapsed Suction Hose	Replace suction hose and service strainer screen
	Air Leak in Suction Hose	Replace hose
	Low Fluid Level	Fill reservoir to proper level
	Over Heated Hydraulic Fluid	Clean oil cooler fins with pressurized water
	Worn Pump or Hydraulic Motor	Adjust, rebuild, or replace as necessary
	Crushed Hydraulic Lines	Replace line
	Engine at Idle	Speed engine up
HYDRAULIC MOTORS DO NOT TURN OR TURN SLOWLY	Product in Tank not Melted	Allow for more time for product to melt
	Foreign Material Jamming Agitator	Remove foreign material from agitator
	Foreign Material Jamming Product Pump	Remove foreign material from product pump
	Flow Controls on Valve Need to be Adjusted	
	Also see "Lack of Performance"	
UNUSAL NOISES	Low Hydraulic Fluid	Fill reservoir to proper level
	Air Leak in Suction Hose	Replace hose
	Damaged Pump or Hydraulic Motors	Repair or replace as necessary
EXCESSIVE OIL LEAKS FROM PUMP OR HYDRAULIC MOTOR SHAFT	Bad Shaft or Shaft Seal	Replace as necessary
	Loose Fittings	Tighten fittings

	<i>POSSIBLE CAUSE</i>	<i>Items to Check /Service</i>
PRODUCT PUMP DOES NOT TURN	Product in Tank not Melted	Allow more time for product to melt
	Foreign Material Jamming Product Pump	Remove foreign material from product pump
	Pump Motor not Functioning	Refer to “Hydraulic System” Trouble Shooting
LACK OF FLOW FROM WAND	Product Temperature too Cold	Heat product to manufacturers recommended temperature
	Product Froze in Wand & Hose	Allow additional time for heating element to melt product in hose
	Non-functioning Heat Element in Hose	Refer to “Electric Wand & Hose” Trouble Shooting
	WPC Valve not Positioned Correctly	Refer to operating instructions for WPC Valve position
	WPC Valve and External Plumbing Froze	Heat to re-melt product
	Worn Product Pump	Adjust or repair product pump as necessary

TROUBLE SHOOTING

Product Pump



TROUBLE SHOOTING

Electric Wand

No heat, or low heat in wand or hose.

With engine OFF, Check for loose pulleys and loose or missing belts on 24 volt alternator.


Start engine, with wand switch OFF check voltage at battery terminal of 24 volt alternator.

24 to 28 volts

With engine running, turn wand switch ON, check voltage at battery terminal of 24 volt alternator.

24 to 28 volts

Check heating elements for an "open" condition. Check for faulty switch. Check for broken wires or loose connections from alternator to switch, and switch to heating elements.



Check for a dead battery, then check for an open resistor or open wires from battery to alternator, or a shorted wire between the alternator and control panel switch and alternator and battery

9 volts or less

12 to 14 volts

Repair or replace alternator


9 volts or less

Check for "short" between switch and heating elements. Alternately disconnect the wires to the hose and wand heating elements, when the voltage goes to 24 - 28 volts you have located the "shorted" circuit.

Check element resistance as follows:

- 15' hose element: .4 to 1.0 W.
- 20' hose element: .5 to 1.2 W.
- Wand element: .9 to 1.6 W.

Repair or replace as necessary.



Primary Controller Burner MTD/Hard Wired

NOTE: *The primary controller can be bench tested for proper operation using an automotive type, 12 volt battery as a power source. Refer to the wiring schematics for wire identification.*



1. Remove controller from burner. Mark all wires for proper reassembly.
2. Using two test lights, or volt meters, connect one to the blue wire, and one to the white/orange wire of the controller. Connect the black leads of your test instruments to the negative (-) terminal of the battery.
3. Connect the black wire from the controller to the negative (-) terminal of the battery.
4. Connect the red, white/red, and the white wires together, then connect these three wires to battery (+) terminal. Both test instruments should show voltage for approximately 15 seconds. After 15 seconds, the controller should "lock out" and no voltage will be present.
5. Repeat step #4, only this time connect the two yellow wires from the controller together three seconds after applying power to the three wires of the controller. (This simulates the controller receiving a "flame" signal from the photo electric eye). The white/orange wire should show voltage as long as the controller is hooked to the battery. The blue wire should only show voltage for about 15 seconds. Replace the controller if it fails any of these tests.





Photo Electric Eye

NOTE: The Photo Electric Eye can be bench tested for proper operation using an ohm meter. Assure the lens of the Photo Electric Eye is clean prior to testing.

1. Block off all light to the Photo Electric Eye. Test across the leads with your ohm meter; you should get an infinite resistance reading (a lot of resistance).
2. Point the Photo Electric Eye at a light source, the brighter the light, the less resistance your ohm meter will show. **CAUTION:** Replace the Photo Electric Eye if it does not respond in this way.



Fuel Valve


NOTE: The Fuel Valve can be bench tested for proper operation using an automotive type 12 volt battery as a power source.

1. Disconnect the two leads and remove the fuel lines from the fuel valve.
2. The valve should be closed when no power is available.
3. Apply 12 volts to the two leads and the valve should open. **CAUTION:** Replace the fuel valve if it does not respond in this way.

Ignition Transformer

WARNING: Shock hazard, high voltage up to 20,000 volts.

1. Assure that 12 volts is being supplied to the transformer during the ignition cycle. (Refer to the Primary Controller tests.)
2. Check electrode condition and adjustment. Replace or adjust as necessary. **CAUTION:** Replace ignition transformer if unit won't produce sparks.





REPLACEMENT PARTS

REPLACEMENT PARTS

SRM Recycler

REVISIONS			
REV.	DESCRIPTION	DATE	APPR
401	RELEASED FOR PROTOTYPE	9/13/2012	

ADDITIONAL INFORMATION:
 FOR LIGHTING SCHEMATIC SEE: S10009438
 FOR OVERALL WIRING SEE: S10009439
 FOR ENGINE WIRING SEE: S10009317
 FOR CONTROL BOX WIRING SEE: S10009399
 FOR HYDRAULIC SCHEMATIC SEE: S10009288-001
 FOR PLUMBING SCHEMATIC SEE: S10009229




STIEPP MFG
 4599RM125C5127049R01
 100 K&S SCALE (48x60x60)
 4599RM125C5127049R01
 100 K&S SCALE (48x60x60)
 4599RM125C5127049R01
 100 K&S SCALE (48x60x60)
 4599RM125C5127049R01
 100 K&S SCALE (48x60x60)
 4599RM125C5127049R01
 100 K&S SCALE (48x60x60)

ITEM NO.	QTY.	PartNo	Description-1	Description-2
70	1	M10011276	SERIAL TAG LASER	
69	1	M10005028-001	SRM CENTER WIRE GUARD	
68	1	K10009025-003	RECYCLER LIGHT PKG	
67	1	A100112177	CONTROL BOX SRM 10' PLC	
66	1	P10009921	HEATER W/ALUM SW/SQ/LN	
65	1	A10009175-001	REC'Y VALVE ASSY-5 BANK	
64	1	A100099430	HOT OIL FINAL ASSY	
63	1	K10009428-007	BOOM, LESS HEAT, ALU W/AND	
62	1	A100111245	PELLET BIN SRM 450# ASSY	
61	1	A10006924-004	COMP ACT CARRIER FINAL ASSY	
60	1	P10004843	TIRE 8 WHEEL 2256/17.5	
59	1	M10009876	CC STANDOFF DOUBLER	
58	1	M10009890	REC'Y CC STANDOFF	
57	1	K10009015-002	SRM WASHDOWN KIT	
56	1	A10009930	SRM SHOVEL CLEANER ASSY	
55	1	A10009881-003	10 C.F. REC'Y HOPPER ASSY	
54	1	A10009499-001	REC'Y TRAILER-670 DLE TANDEM	
53	1	A10004851-002	SPARE TIRE CARRIER BOLT ON	
52	1	A100093483	BREAK AWAY SWITCH W/CONNECTOR	
51	2	A10009334-001	BLACK VINYL	
50	1	M10009932-001	BLACK VINYL LABEL	
49	1	M10009932-001	BLACK VINYL LABEL	
48	1	A10009181-001	SRM HOSE TUBE ASSY	
47	1	A10008702-001	SRM WORK PLAT ASSY	
46	1	A10008225-002	1505 STD. STD. C/TRES SIRT	
45	4	P10003134-002	POP RIVET CLOSED END	
44	9	P10003139	SCREW SELF DRILL	
43	5	P100039051	GRIPSEET 1/4-20X3C	
42	6	P10001608-006	WASHER	
41	10	P10001608-004	WASHER	
40	4	P10001609-008	WASHER	
39	4	P10001605-007	BOLT	
38	4	P10001605-003	BOLT	
37	10	P10001601-001	BOLT	
36	6	P10001600-005	NUT HEX	
35	2	P10004456-036	FLEX HOSE-1" MNPT X F JIC	
34	4	P10001639-002	ELL-3T-90#	
33	2	P10001048-002	ELBOW-3T-45#	
32	1	T10009432	HOT OIL PROCEDURE	
31	1	T10009431	SRM HOT OIL CHART	
30	1	M10008705	SRM PLAT-SIRT DEFECT	
29	1	M10008704	SRM PLAT-SIRT DEFLECT	
28	1	M100095030	WIRE GUARD	
27	1	M100095029	WIRE GUARD	
26	1	M10002416-003	NUMBER TAG-3	
25	1	A10009784	REC'Y FINAL FLUSH ASSY	
24	1	A100098976	35 GAL HYD. TANK ASSY	
23	1	A10008890	SRM MAT. PLATFORM ASSY	
22	1	A10008792	60 GAL FUEL TANK ASSY	
21	1	A10007857-062	HOSE-1-1/2 SUCTION	
20	1	A10007861-120	HOSE-FUEL ASSY	
19	1	A10007861-030	HOSE-FUEL ASSY	
18	1	A10007861-015	HOSE-FUEL ASSY	
17	2	A10007875-000	HOSE-PROD.-1" x LENGTH	
16	1	A10007867-096	HOSE ASSY-3/4-HYD HIGH	
15	1	A10007867-052	HOSE ASSY-3/4-HYD HIGH	
14	1	A10007867-048	HOSE ASSY-3/4-HYD HIGH	
13	1	A10007864-036	HOSE ASSY-3/8-HYD HIGH	
12	2	A10007859-034	HOSE-1/2-HYD HIGH ASSY	
11	2	A10007853-000	HOSE-1/2-HYD HIGH ASSY	
10	2	A10007852-095	HOSE-1/2-HYD HIGH ASSY	
9	3	A10007850-036	HOSE-1/2-HYD HIGH ASSY	
8	2	A10007849-024	HOSE-1/2-HYD HIGH ASSY	
7	1	A10007850-054	HOSE-1/4-HYD HIGH ASSY	
6	1	A10007850-036	HOSE-1/4-HYD HIGH ASSY	
5	1	A10007188	CONVEY SUPPORT LEG ASSY	
4	3	A10006475	LOADER CONVEYOR ASSY	
3	1	A10006025	FILTER ASSY	
2	1	A10005104-006	FINAL BATTERY BOX ASSY	
1	1	M10005668	STROBE LIGHT MFG BRACKET	


REPLACEMENT PARTS


Pugmill & Mixing Chamber




REPLACEMENT PARTS



Pugmill & Mixing Chamber









STEFF MFG.
1000 W. 10th St.
Steff, MN 55078
612-835-5555
www.steffmfg.com



REPLACEMENT PARTS

Pugmill & Mixing Chamber


- ASSEMBLY INSTRUCTIONS:
1. WELD CYLINDER BRACKET TO HOPPER
 2. WELD VALVE HANDLE TO BALL VALVE
 3. PAINT PLUMBING BLACK
 4. PAINT HOPPER SPECIFIED COLOR
 5. ASSEMBLE HOPPER FINA.



STOP HERE


REPLACEMENT PARTS

Pugmill & Mixing Chamber




REPLACEMENT PARTS

Pugmill & Mixing Chamber



REPLACEMENT PARTS

Pugmill & Mixing Chamber






1. Nut
2. Washer
3. Bolt
4. Roller
5. Bolt
6. Washer
7. Nut
8. Bolt
9. Washer
10. Nut
11. Bolt
12. Washer
13. Nut
14. Bolt
15. Washer
16. Nut
17. Bolt
18. Washer
19. Nut
20. Bolt
21. Washer
22. Nut
23. Bolt
24. Washer
25. Nut
26. Bolt
27. Washer
28. Nut
29. Bolt
30. Washer


31. Motor
32. Gear
33. Shaft
34. Pulley
35. Bolt
36. Washer
37. Nut
38. Bolt
39. Washer
40. Nut
41. Bolt
42. Washer
43. Nut
44. Bolt
45. Washer
46. Nut
47. Bolt
48. Washer
49. Nut
50. Bolt
51. Washer
52. Nut
53. Bolt
54. Washer
55. Nut
56. Bolt
57. Washer
58. Nut
59. Bolt
60. Washer
61. Nut
62. Bolt
63. Washer
64. Nut
65. Bolt
66. Washer
67. Nut
68. Bolt
69. Washer
70. Nut
71. Bolt
72. Washer
73. Nut
74. Bolt
75. Washer
76. Nut
77. Bolt
78. Washer
79. Nut
80. Bolt
81. Washer
82. Nut
83. Bolt
84. Washer
85. Nut
86. Bolt
87. Washer
88. Nut
89. Bolt
90. Washer
91. Nut
92. Bolt
93. Washer
94. Nut
95. Bolt
96. Washer
97. Nut
98. Bolt
99. Washer
100. Nut
101. Bolt
102. Washer
103. Nut
104. Bolt
105. Washer
106. Nut
107. Bolt
108. Washer
109. Nut
110. Bolt
111. Washer
112. Nut
113. Bolt
114. Washer
115. Nut
116. Bolt
117. Washer
118. Nut
119. Bolt
120. Washer
121. Nut
122. Bolt
123. Washer
124. Nut
125. Bolt
126. Washer
127. Nut
128. Bolt
129. Washer
130. Nut
131. Bolt
132. Washer
133. Nut
134. Bolt
135. Washer
136. Nut
137. Bolt
138. Washer
139. Nut
140. Bolt
141. Washer
142. Nut
143. Bolt
144. Washer
145. Nut
146. Bolt
147. Washer
148. Nut
149. Bolt
150. Washer
151. Nut
152. Bolt
153. Washer
154. Nut
155. Bolt
156. Washer
157. Nut
158. Bolt
159. Washer
160. Nut
161. Bolt
162. Washer
163. Nut
164. Bolt
165. Washer
166. Nut
167. Bolt
168. Washer
169. Nut
170. Bolt
171. Washer
172. Nut
173. Bolt
174. Washer
175. Nut
176. Bolt
177. Washer
178. Nut
179. Bolt
180. Washer
181. Nut
182. Bolt
183. Washer
184. Nut
185. Bolt
186. Washer
187. Nut
188. Bolt
189. Washer
190. Nut
191. Bolt
192. Washer
193. Nut
194. Bolt
195. Washer
196. Nut
197. Bolt
198. Washer
199. Nut
200. Bolt
201. Washer
202. Nut
203. Bolt
204. Washer
205. Nut
206. Bolt
207. Washer
208. Nut
209. Bolt
210. Washer
211. Nut
212. Bolt
213. Washer
214. Nut
215. Bolt
216. Washer
217. Nut
218. Bolt
219. Washer
220. Nut
221. Bolt
222. Washer
223. Nut
224. Bolt
225. Washer
226. Nut
227. Bolt
228. Washer
229. Nut
230. Bolt
231. Washer
232. Nut
233. Bolt
234. Washer
235. Nut
236. Bolt
237. Washer
238. Nut
239. Bolt
240. Washer
241. Nut
242. Bolt
243. Washer
244. Nut
245. Bolt
246. Washer
247. Nut
248. Bolt
249. Washer
250. Nut
251. Bolt
252. Washer
253. Nut
254. Bolt
255. Washer
256. Nut
257. Bolt
258. Washer
259. Nut
260. Bolt
261. Washer
262. Nut
263. Bolt
264. Washer
265. Nut
266. Bolt
267. Washer
268. Nut
269. Bolt
270. Washer
271. Nut
272. Bolt
273. Washer
274. Nut
275. Bolt
276. Washer
277. Nut
278. Bolt
279. Washer
280. Nut
281. Bolt
282. Washer
283. Nut
284. Bolt
285. Washer
286. Nut
287. Bolt
288. Washer
289. Nut
290. Bolt
291. Washer
292. Nut
293. Bolt
294. Washer
295. Nut
296. Bolt
297. Washer
298. Nut
299. Bolt
300. Washer
301. Nut
302. Bolt
303. Washer
304. Nut
305. Bolt
306. Washer
307. Nut
308. Bolt
309. Washer
310. Nut
311. Bolt
312. Washer
313. Nut
314. Bolt
315. Washer
316. Nut
317. Bolt
318. Washer
319. Nut
320. Bolt
321. Washer
322. Nut
323. Bolt
324. Washer
325. Nut
326. Bolt
327. Washer
328. Nut
329. Bolt
330. Washer
331. Nut
332. Bolt
333. Washer
334. Nut
335. Bolt
336. Washer
337. Nut
338. Bolt
339. Washer
340. Nut
341. Bolt
342. Washer
343. Nut
344. Bolt
345. Washer
346. Nut
347. Bolt
348. Washer
349. Nut
350. Bolt
351. Washer
352. Nut
353. Bolt
354. Washer
355. Nut
356. Bolt
357. Washer
358. Nut
359. Bolt
360. Washer
361. Nut
362. Bolt
363. Washer
364. Nut
365. Bolt
366. Washer
367. Nut
368. Bolt
369. Washer
370. Nut
371. Bolt
372. Washer
373. Nut
374. Bolt
375. Washer
376. Nut
377. Bolt
378. Washer
379. Nut
380. Bolt
381. Washer
382. Nut
383. Bolt
384. Washer
385. Nut
386. Bolt
387. Washer
388. Nut
389. Bolt
390. Washer
391. Nut
392. Bolt
393. Washer
394. Nut
395. Bolt
396. Washer
397. Nut
398. Bolt
399. Washer
400. Nut
401. Bolt
402. Washer
403. Nut
404. Bolt
405. Washer
406. Nut
407. Bolt
408. Washer
409. Nut
410. Bolt
411. Washer
412. Nut
413. Bolt
414. Washer
415. Nut
416. Bolt
417. Washer
418. Nut
419. Bolt
420. Washer
421. Nut
422. Bolt
423. Washer
424. Nut
425. Bolt
426. Washer
427. Nut
428. Bolt
429. Washer
430. Nut
431. Bolt
432. Washer
433. Nut
434. Bolt
435. Washer
436. Nut
437. Bolt
438. Washer
439. Nut
440. Bolt
441. Washer
442. Nut
443. Bolt
444. Washer
445. Nut
446. Bolt
447. Washer
448. Nut
449. Bolt
450. Washer
451. Nut
452. Bolt
453. Washer
454. Nut
455. Bolt
456. Washer
457. Nut
458. Bolt
459. Washer
460. Nut
461. Bolt
462. Washer
463. Nut
464. Bolt
465. Washer
466. Nut
467. Bolt
468. Washer
469. Nut
470. Bolt
471. Washer
472. Nut
473. Bolt
474. Washer
475. Nut
476. Bolt
477. Washer
478. Nut
479. Bolt
480. Washer
481. Nut
482. Bolt
483. Washer
484. Nut
485. Bolt
486. Washer
487. Nut
488. Bolt
489. Washer
490. Nut
491. Bolt
492. Washer
493. Nut
494. Bolt
495. Washer
496. Nut
497. Bolt
498. Washer
499. Nut
500. Bolt
501. Washer
502. Nut
503. Bolt
504. Washer
505. Nut
506. Bolt
507. Washer
508. Nut
509. Bolt
510. Washer
511. Nut
512. Bolt
513. Washer
514. Nut
515. Bolt
516. Washer
517. Nut
518. Bolt
519. Washer
520. Nut
521. Bolt
522. Washer
523. Nut
524. Bolt
525. Washer
526. Nut
527. Bolt
528. Washer
529. Nut
530. Bolt
531. Washer
532. Nut
533. Bolt
534. Washer
535. Nut
536. Bolt
537. Washer
538. Nut
539. Bolt
540. Washer
541. Nut
542. Bolt
543. Washer
544. Nut
545. Bolt
546. Washer
547. Nut
548. Bolt
549. Washer
550. Nut
551. Bolt
552. Washer
553. Nut
554. Bolt
555. Washer
556. Nut
557. Bolt
558. Washer
559. Nut
560. Bolt
561. Washer
562. Nut
563. Bolt
564. Washer
565. Nut
566. Bolt
567. Washer
568. Nut
569. Bolt
570. Washer
571. Nut
572. Bolt
573. Washer
574. Nut
575. Bolt
576. Washer
577. Nut
578. Bolt
579. Washer
580. Nut
581. Bolt
582. Washer
583. Nut
584. Bolt
585. Washer
586. Nut
587. Bolt
588. Washer
589. Nut
590. Bolt
591. Washer
592. Nut
593. Bolt
594. Washer
595. Nut
596. Bolt
597. Washer
598. Nut
599. Bolt
600. Washer
601. Nut
602. Bolt
603. Washer
604. Nut
605. Bolt
606. Washer
607. Nut
608. Bolt
609. Washer
610. Nut
611. Bolt
612. Washer
613. Nut
614. Bolt
615. Washer
616. Nut
617. Bolt
618. Washer
619. Nut
620. Bolt
621. Washer
622. Nut
623. Bolt
624. Washer
625. Nut
626. Bolt
627. Washer
628. Nut
629. Bolt
630. Washer
631. Nut
632. Bolt
633. Washer
634. Nut
635. Bolt
636. Washer
637. Nut
638. Bolt
639. Washer
640. Nut
641. Bolt
642. Washer
643. Nut
644. Bolt
645. Washer
646. Nut
647. Bolt
648. Washer
649. Nut
650. Bolt
651. Washer
652. Nut
653. Bolt
654. Washer
655. Nut
656. Bolt
657. Washer
658. Nut
659. Bolt
660. Washer
661. Nut
662. Bolt
663. Washer
664. Nut
665. Bolt
666. Washer
667. Nut
668. Bolt
669. Washer
670. Nut
671. Bolt
672. Washer
673. Nut
674. Bolt
675. Washer
676. Nut
677. Bolt
678. Washer
679. Nut
680. Bolt
681. Washer
682. Nut
683. Bolt
684. Washer
685. Nut
686. Bolt
687. Washer
688. Nut
689. Bolt
690. Washer
691. Nut
692. Bolt
693. Washer
694. Nut
695. Bolt
696. Washer
697. Nut
698. Bolt
699. Washer
700. Nut
701. Bolt
702. Washer
703. Nut
704. Bolt
705. Washer
706. Nut
707. Bolt
708. Washer
709. Nut
710. Bolt
711. Washer
712. Nut
713. Bolt
714. Washer
715. Nut
716. Bolt
717. Washer
718. Nut
719. Bolt
720. Washer
721. Nut
722. Bolt
723. Washer
724. Nut
725. Bolt
726. Washer
727. Nut
728. Bolt
729. Washer
730. Nut
731. Bolt
732. Washer
733. Nut
734. Bolt
735. Washer
736. Nut
737. Bolt
738. Washer
739. Nut
740. Bolt
741. Washer
742. Nut
743. Bolt
744. Washer
745. Nut
746. Bolt
747. Washer
748. Nut
749. Bolt
750. Washer
751. Nut
752. Bolt
753. Washer
754. Nut
755. Bolt
756. Washer
757. Nut
758. Bolt
759. Washer
760. Nut
761. Bolt
762. Washer
763. Nut
764. Bolt
765. Washer
766. Nut
767. Bolt
768. Washer
769. Nut
770. Bolt
771. Washer
772. Nut
773. Bolt
774. Washer
775. Nut
776. Bolt
777. Washer
778. Nut
779. Bolt
780. Washer
781. Nut
782. Bolt
783. Washer
784. Nut
785. Bolt
786. Washer
787. Nut
788. Bolt
789. Washer
790. Nut
791. Bolt
792. Washer
793. Nut
794. Bolt
795. Washer
796. Nut
797. Bolt
798. Washer
799. Nut
800. Bolt
801. Washer
802. Nut
803. Bolt
804. Washer
805. Nut
806. Bolt
807. Washer
808. Nut
809. Bolt
810. Washer
811. Nut
812. Bolt
813. Washer
814. Nut
815. Bolt
816. Washer
817. Nut
818. Bolt
819. Washer
820. Nut
821. Bolt
822. Washer
823. Nut
824. Bolt
825. Washer
826. Nut
827. Bolt
828. Washer
829. Nut
830. Bolt
831. Washer
832. Nut
833. Bolt
834. Washer
835. Nut
836. Bolt
837. Washer
838. Nut
839. Bolt
840. Washer
841. Nut
842. Bolt
843. Washer
844. Nut
845. Bolt
846. Washer
847. Nut
848. Bolt
849. Washer
850. Nut
851. Bolt
852. Washer
853. Nut
854. Bolt
855. Washer
856. Nut
857. Bolt
858. Washer
859. Nut
860. Bolt
861. Washer
862. Nut
863. Bolt
864. Washer
865. Nut
866. Bolt
867. Washer
868. Nut
869. Bolt
870. Washer
871. Nut
872. Bolt
873. Washer
874. Nut
875. Bolt
876. Washer
877. Nut
878. Bolt
879. Washer
880. Nut
881. Bolt
882. Washer
883. Nut
884. Bolt
885. Washer
886. Nut
887. Bolt
888. Washer
889. Nut
890. Bolt
891. Washer
892. Nut
893. Bolt
894. Washer
895. Nut
896. Bolt
897. Washer
898. Nut
899. Bolt
900. Washer
901. Nut
902. Bolt
903. Washer
904. Nut
905. Bolt
906. Washer
907. Nut
908. Bolt
909. Washer
910. Nut
911. Bolt
912. Washer
913. Nut
914. Bolt
915. Washer
916. Nut
917. Bolt
918. Washer
919. Nut
920. Bolt
921. Washer
922. Nut
923. Bolt
924. Washer
925. Nut
926. Bolt
927. Washer
928. Nut
929. Bolt
930. Washer
931. Nut
932. Bolt
933. Washer
934. Nut
935. Bolt
936. Washer
937. Nut
938. Bolt
939. Washer
940. Nut
941. Bolt
942. Washer
943. Nut
944. Bolt
945. Washer
946. Nut
947. Bolt
948. Washer
949. Nut
950. Bolt
951. Washer
952. Nut
953. Bolt
954. Washer
955. Nut
956. Bolt
957. Washer
958. Nut
959. Bolt
960. Washer
961. Nut
962. Bolt
963. Washer
964. Nut
965. Bolt
966. Washer
967. Nut
968. Bolt
969. Washer
970. Nut
971. Bolt
972. Washer
973. Nut
974. Bolt
975. Washer
976. Nut
977. Bolt
978. Washer
979. Nut
980. Bolt
981. Washer
982. Nut
983. Bolt
984. Washer
985. Nut
986. Bolt
987. Washer
988. Nut
989. Bolt
990. Washer
991. Nut
992. Bolt
993. Washer
994. Nut
995. Bolt
996. Washer
997. Nut
998. Bolt
999. Washer
1000. Nut

REPLACEMENT PARTS

Pugmill & Mixing Chamber




DO NOT WELD RIMS
TO TANK MOUNTS






REPLACEMENT PARTS


Pugmill & Mixing Chamber




REPLACEMENT PARTS

Pugmill & Mixing Chamber









REPLACEMENT PARTS

Pugmill & Mixing Chamber



REPLACEMENT PARTS


Pugmill & Mixing Chamber



REPLACEMENT PARTS

Oil Kettle and Pumping System

DASH NO. PER PART REQUIREMENT		DESCRIPTION
DASH NO.	QTY.	PART NO.
01	1	1-000000
02	1	1-000001
03	1	1-000002
04	1	1-000003
05	1	1-000004
06	1	1-000005
07	1	1-000006
08	1	1-000007
09	1	1-000008
10	1	1-000009
11	1	1-000010
12	1	1-000011
13	1	1-000012
14	1	1-000013
15	1	1-000014
16	1	1-000015
17	1	1-000016
18	1	1-000017
19	1	1-000018
20	1	1-000019
21	1	1-000020
22	1	1-000021
23	1	1-000022
24	1	1-000023
25	1	1-000024
26	1	1-000025
27	1	1-000026
28	1	1-000027
29	1	1-000028
30	1	1-000029
31	1	1-000030
32	1	1-000031
33	1	1-000032
34	1	1-000033
35	1	1-000034
36	1	1-000035
37	1	1-000036
38	1	1-000037
39	1	1-000038
40	1	1-000039
41	1	1-000040
42	1	1-000041
43	1	1-000042
44	1	1-000043
45	1	1-000044
46	1	1-000045
47	1	1-000046
48	1	1-000047
49	1	1-000048
50	1	1-000049
51	1	1-000050
52	1	1-000051
53	1	1-000052
54	1	1-000053
55	1	1-000054
56	1	1-000055
57	1	1-000056
58	1	1-000057
59	1	1-000058
60	1	1-000059
61	1	1-000060
62	1	1-000061
63	1	1-000062
64	1	1-000063
65	1	1-000064
66	1	1-000065
67	1	1-000066
68	1	1-000067
69	1	1-000068
70	1	1-000069
71	1	1-000070
72	1	1-000071
73	1	1-000072
74	1	1-000073
75	1	1-000074
76	1	1-000075
77	1	1-000076
78	1	1-000077
79	1	1-000078
80	1	1-000079
81	1	1-000080
82	1	1-000081
83	1	1-000082
84	1	1-000083
85	1	1-000084
86	1	1-000085
87	1	1-000086
88	1	1-000087
89	1	1-000088
90	1	1-000089
91	1	1-000090
92	1	1-000091
93	1	1-000092
94	1	1-000093
95	1	1-000094
96	1	1-000095
97	1	1-000096
98	1	1-000097
99	1	1-000098
100	1	1-000099
101	1	1-000100




REPLACEMENT PARTS


Oil Kettle and Pumping System

DASH NO. PER PART REQUIREMENT

DASH NO.	QTY.	PART NO.	DESCRIPTION
400	1/2	100000000	W/1 W/12A
401	1/2	100000001	BLACK PAINT
402	1/2	100000002	SPALLS LUMV
403	1/2	100000003	CONNECT
404	1/2	100000004	VALVE RT 111M
405	1/2	100000005	BRAND 100000005




STEP 1
Remove the top cover of the oil kettle. Refer to the exploded view for the correct removal sequence. The top cover is held in place by several screws. Use a screwdriver to remove these screws. Once removed, lift the top cover off the kettle and set it aside.



REPLACEMENT PARTS

Oil Kettle and Pumping System



REPLACEMENT PARTS

Heated and Non-Heated Overhead Boom

1. 2015-2016

FORWARD STORAGE POSITION
AND BRACKETS TO BE DETERMINED

2.

3.

4.

5.

6.

7.

8.

9.

10.

11.


12.

13.

14.


15.

16.



REPLACEMENT PARTS


Heated Spray Wand



WELD TOGETHER IN CLOSED POSITION
AT POSITION PIVOT AND LINKAGE AS
NECESSARY FOR OPERATION

REPLACEMENT PARTS

Heated Hose




Design Table for A1007650


QTY	DESCRIPTION	QTY	QTY	QTY	QTY	QTY
0	A1007650-100	97	111	102	102	277
0	A1007650-107	137	161	151	151	277
0	A1007650-137	177	213	191	191	277
0	A1007650-177	227	273	247	247	277
0	A1007650-227	277	277	277	277	277



REPLACEMENT PARTS

Non-Heated Spray Wand









REPLACEMENT PARTS

Conveyor

Part No.	Part Name	Part No.	Part Name
400	ROLLER	410	ROLLER
401	ROLLER	411	ROLLER
402	ROLLER	412	ROLLER
403	ROLLER	413	ROLLER



Part No.	Part Name	Part No.	Part Name
400	ROLLER	410	ROLLER
401	ROLLER	411	ROLLER
402	ROLLER	412	ROLLER
403	ROLLER	413	ROLLER
404	ROLLER	414	ROLLER
405	ROLLER	415	ROLLER
406	ROLLER	416	ROLLER
407	ROLLER	417	ROLLER
408	ROLLER	418	ROLLER
409	ROLLER	419	ROLLER
410	ROLLER	420	ROLLER




Part No.	Part Name	Part No.	Part Name
400	ROLLER	410	ROLLER
401	ROLLER	411	ROLLER
402	ROLLER	412	ROLLER
403	ROLLER	413	ROLLER
404	ROLLER	414	ROLLER
405	ROLLER	415	ROLLER
406	ROLLER	416	ROLLER
407	ROLLER	417	ROLLER
408	ROLLER	418	ROLLER
409	ROLLER	419	ROLLER
410	ROLLER	420	ROLLER

REPLACEMENT PARTS


Trailer With Electric Brakes



1. HITCH ASSEMBLY




NOTE:
LOOBTIGHT ALL FASTENERS
EXCEPT - LUG NUTS AND HITCH BOLTS




REPLACEMENT PARTS

Trailer With Hydraulic Brakes





REPLACEMENT PARTS

Trailer










REPLACEMENT PARTS

Trailer






WIRE COLORS







STEP 1
STEP 2
STEP 3
STEP 4
STEP 5
STEP 6
STEP 7
STEP 8
STEP 9
STEP 10
STEP 11
STEP 12
STEP 13
STEP 14
STEP 15
STEP 16
STEP 17
STEP 18
STEP 19
STEP 20
STEP 21
STEP 22
STEP 23
STEP 24
STEP 25
STEP 26
STEP 27
STEP 28
STEP 29
STEP 30
STEP 31
STEP 32
STEP 33
STEP 34
STEP 35
STEP 36
STEP 37
STEP 38
STEP 39
STEP 40
STEP 41
STEP 42
STEP 43
STEP 44
STEP 45
STEP 46
STEP 47
STEP 48
STEP 49
STEP 50
STEP 51
STEP 52
STEP 53
STEP 54
STEP 55
STEP 56
STEP 57
STEP 58
STEP 59
STEP 60
STEP 61
STEP 62
STEP 63
STEP 64
STEP 65
STEP 66
STEP 67
STEP 68
STEP 69
STEP 70
STEP 71
STEP 72
STEP 73
STEP 74
STEP 75
STEP 76
STEP 77
STEP 78
STEP 79
STEP 80
STEP 81
STEP 82
STEP 83
STEP 84
STEP 85
STEP 86
STEP 87
STEP 88
STEP 89
STEP 90
STEP 91
STEP 92
STEP 93
STEP 94
STEP 95
STEP 96
STEP 97
STEP 98
STEP 99
STEP 100



REPLACEMENT PARTS


Engine



STPP MFG
STEP 1 MFG
STEP 2 MFG
STEP 3 MFG
STEP 4 MFG
STEP 5 MFG
STEP 6 MFG
STEP 7 MFG
STEP 8 MFG
STEP 9 MFG
STEP 10 MFG
STEP 11 MFG
STEP 12 MFG
STEP 13 MFG
STEP 14 MFG
STEP 15 MFG
STEP 16 MFG
STEP 17 MFG
STEP 18 MFG
STEP 19 MFG
STEP 20 MFG
STEP 21 MFG
STEP 22 MFG
STEP 23 MFG
STEP 24 MFG
STEP 25 MFG
STEP 26 MFG
STEP 27 MFG
STEP 28 MFG
STEP 29 MFG
STEP 30 MFG
STEP 31 MFG
STEP 32 MFG
STEP 33 MFG
STEP 34 MFG
STEP 35 MFG
STEP 36 MFG
STEP 37 MFG
STEP 38 MFG
STEP 39 MFG
STEP 40 MFG
STEP 41 MFG
STEP 42 MFG
STEP 43 MFG
STEP 44 MFG
STEP 45 MFG
STEP 46 MFG
STEP 47 MFG
STEP 48 MFG
STEP 49 MFG
STEP 50 MFG
STEP 51 MFG
STEP 52 MFG
STEP 53 MFG
STEP 54 MFG
STEP 55 MFG
STEP 56 MFG
STEP 57 MFG
STEP 58 MFG
STEP 59 MFG
STEP 60 MFG
STEP 61 MFG
STEP 62 MFG
STEP 63 MFG
STEP 64 MFG
STEP 65 MFG
STEP 66 MFG
STEP 67 MFG
STEP 68 MFG
STEP 69 MFG
STEP 70 MFG
STEP 71 MFG
STEP 72 MFG
STEP 73 MFG
STEP 74 MFG
STEP 75 MFG
STEP 76 MFG
STEP 77 MFG
STEP 78 MFG
STEP 79 MFG
STEP 80 MFG
STEP 81 MFG
STEP 82 MFG
STEP 83 MFG
STEP 84 MFG
STEP 85 MFG
STEP 86 MFG
STEP 87 MFG
STEP 88 MFG
STEP 89 MFG
STEP 90 MFG
STEP 91 MFG
STEP 92 MFG
STEP 93 MFG
STEP 94 MFG
STEP 95 MFG
STEP 96 MFG
STEP 97 MFG
STEP 98 MFG
STEP 99 MFG
STEP 100 MFG







REPLACEMENT PARTS


Hydraulics



REPLACEMENT PARTS


Controls





REPLACEMENT PARTS

Controls




NOTE: DOCUMENT LENGTHS REQUIRED
ON PRINT AND RETURN TO ENGINEERING




REPLACEMENT PARTS

Compactor Plate Carrier







REPLACEMENT PARTS

Washdown




REPLACEMENT PARTS

Fuel Filter




REPLACEMENT PARTS

Burner Liner




REPLACEMENT PARTS

Diesel Burner



F HEAD FIRING RATE CHART

HEAD	F-3	F-8	F-12	F-22	F-31
MIN. FIRING RATE	75	1.25	1.85	1.75	2.50
MAX. FIRING RATE	1.25	1.65	2.00	2.50	3.00



NOZZLE FLOW CHART

100 PSI	.75	.85	.90	1.00	1.10	1.20	1.25	1.35	1.50	1.65	1.75	2.00	2.25	2.50	2.75	3.00
140 PSI	.80	1.00	1.07	1.18	1.30	1.41	1.48	1.60	1.78	1.95	2.07	2.37	2.65	2.96	3.25	3.55


ITEM	QTY	DESCRIPTION	PART#
1	1	Burner, fuel oil, Beckett Assembly	A10008105-011
2	1	Air Tube	509070
3	1	Photo electric eye w/connectors (under ignition transformer)	A10007678
4	1	Valve, fuel control	509091
5	1	Ignition Transformer	509087
6	1	Primary Controller	A10008216
7	1	Motor, fan and pump	509092
8	1	Coupling, pump to motor	509086
9	1	Pump, burner fuel	509094
10	1	Fuel retention head, F31	P10005130
11	1	Nozzle, .3.0 GPM	P10005133
12	1	Electrode kit, igniter	509089
13	1	Mounting Flange	509071
**	1	Brush kit, motor	509072
**	1	Fuel Filter Element	509078

** Not Shown

Note: Nozzle GPH rated at 100 psi.

REPLACEMENT PARTS

8'/12' Heated Hose



ITEM	QTY	DESCRIPTION	PART #
1	1	8' Hose Assembly with heating element	523089
	1	12' Hose Assembly with heating element	523093
1a	1	Compression Fitting 3/8"	M10009910
1b	1	8' Heating element, for hose, includes **connector	A10009933
	1	12' Heating element, for hose, includes **connector	A10009934
1c	1	8' Hose Assembly, less heating element	A10007890-087
	1	12' Hose Assembly, less heating element	A10007890-137
1d	AR	Safety Jacket, specify length	P10008320
1e	2	Clamp assembly	523087
**	1	Wire Harness & Connectors (in hose jacket)	see next pg.
2	1	Bushing, reducing	P10004952-009
3	1	Bushing, reducing	P10004952-011
4	1	Quick Coupling, female	P10009965
4a	1	Seal, quick coupling	509999
**	1	1/2" Compression Fitting (for 15', 20' hoses, & 62" elements).....	M10011276

** - Not Shown

Indented item numbers with a letter suffix are included with preceding item number.

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.

REPLACEMENT PARTS

Ortec Hose




ITEM	QTY	DESCRIPTION	PART #
-	1	Hose, yellow ortec, 1/2" x 20 ft. (with fittings).....	523055
-	1	Hose, yellow ortec, 1/2" x 25 ft. (with fittings).....	523006
-	1	Hose, yellow ortec, 1/2" x 40 ft. (with fittings).....	523021
-	1	Hose, yellow ortec, 1/2" bulk per foot (no fittings).....	P10007809
-	1	Hose, yellow ortec, 3/4" x 15 ft. (with fittings).....	523007
-	1	Hose, yellow ortec, 3/4" x 20 ft. (with fittings).....	523054
-	1	Hose, yellow ortec, 3/4" x 25 ft. (with fittings).....	523075
-		Hose, yellow ortec, 3/4" bulk per foot (no fittings).....	P10007810
-	1	Hose, yellow ortec, 1" x 15 ft. (with fittings).....	523008
-	1	Hose, yellow ortec, 1" x 20 ft. (with fittings).....	523015
-	1	Hose, yellow ortec, 1" x 25 ft. (with fittings).....	523010
-		Hose, yellow ortec, 1" bulk per foot (no fittings).....	P10007811

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.

REPLACEMENT PARTS

HL-32 Pump



ITEM	QTY	DESCRIPTION	PART#
1	1	Pump, complete with relief valve	515006
	1	Pump, complete without relief valve, with steel rotor (OJK-50, 75, 120).....	515063
	1	Pump, complete without relief valve, with standard rotor	515005
2	5	Packing seal, shaft.....	515019
3	1	Bushing, bracket	515041
4	1	Rotor and Shaft	515031
5	1	Idler with bushing	515015
6	1	Bushing	515053
7	1	Gasket set, head - (for setting end clearance).....	515016
8	1	Idler Pin	515052
9	1	Head, for pumps without relief valve (includes # 7).....	515028
	1	Head, for pumps with relief valve (includes # 7).....	515027
10	1	Gasket, relief valve	515083
11	1	Relief Valve	515055

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.


REPLACEMENT PARTS

Spray Nozzles For Spray Bars and Spray Wands



ITEM	QTY	DESCRIPTION	PART #
1	-	Nozzle, Duckbill, 2½" Elkhart #184.....	P-160
2	-	V-Jet Nozzle, H¼VV9508 (for spray wands).....	P10002943
3	-	V-Jet Nozzle, H¼U4070 (for spray bars)	520088
	-	V-Jet Nozzle, H¼U6515 (for spray bars)	P10002944
	-	V-Jet Nozzle, H¼U6520 (for spray bars)	P10005342
	-	V-Jet Nozzle, H¼U6530 (for spray bars)	P10005343
	-	V-Jet Nozzle, H¼U6540 (for spray bars)	P10005340
	-	V-Jet Nozzle, H¼U6550 (for spray bars)	P10005345
	-	V-Jet Nozzle, H¼U6560 (for spray bars)	P10005346
	-	V-Jet Nozzle, H¼U6570 (for spray bars)	P10005347
	-	V-Jet Nozzle, H3/8U65100 (for spray bars)	520042
4	-	Duck Bill Nozzle Assy.	A10010564


Example:



Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.

REPLACEMENT PARTS

**Burner Filters
For Diesel Burner and LP Systems**



ITEM	QTY	DESCRIPTION	PART #
1	1	Fuel Filter Element, Diesel Burner (includes gaskets)	509078
2	1	LP Fuel Filter Element, LP Burners (includes gaskets)	509028

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.

REPLACEMENT PARTS

Chassis Lighting Connectors



1



2



3

4



5

6




ITEM	QTY	DESCRIPTION	PART#
1	1	Connector-7 Pin Flat Female	48485
2	1	Connector-7 Pin Flat Male.....	P10002841
3	1	Connector-7 Pin Round Female.....	526017
4	1	Connector-7 Pin Round Male	P10002840
5	1	Connector-6 Pin Round Female.....	P10002838
6	1	Connector-6 Pin Round Male	P10002839
0	1	Connector-4 Pin Round Female.....	526103
0	1	Connector 4 Pin Round Male	526014
0	1	Connector 9 Pin Round Female.....	P10002758
0	1	Connector 9 Pin Round Male	P10002562

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.

REPLACEMENT PARTS

Chassis Lighting—Grommeted Lights





ITEM	QTY	DESCRIPTION	PART#
1	1	Oval Red Taillight 6"	P10002899
2	1	Oval Red Taillight LED 6"	P10007080
3	1	Round Red Taillight	P10002896
4	1	Round Red LED Taillight 4"	44030R
5	1	Round Red Clearance Light 2.5"	P10002892
6	1	Round Amber Clearance Light 2.5"	P10002893
7	1	Round Amber Clearance Light LED 2.5"	P10002894
8	1	Round Red Clearance Light LED 2.5"	P10002891

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.
 Note: All light kits include light, mounting grommet and wire pigtail.

REPLACEMENT PARTS

Chassis



ITEM	QTY	DESCRIPTION	PART#
1	1	Screw Jack, 15" body.....	501051
	1	Screw Jack, 20" body.....	P10001273
2	1	Ring Hitch.....	W10004075
00	1	Ball Hitch, 2 5/16"	901038
00	1	Ring hitch-model 10 actuator, hydraulic brakes	901317
00	1	Right hitch-model 20 actuator, hydraulic brakes	901317A

Note: Illustrations are for parts identification only. Illustrations may not represent actual parts.

REPLACEMENT PARTS

Miscellaneous

CONVEYOR ASSEMBLY	P/N
Belt Conveyor 18"x332"	P10006477
Hydraulic Motor	P10006578
Sprocket #50 Chain 1" Bore	P10006471
Chain- 50# Roller	P10006227
Master Link #50	P10006480

ENGINE	P/N
Engine Cabinet	A10008210
1505 Engine Assembly	A10008263-002
Includes:	
Fuel Pump 12 volt DC	P10000156
Kubota 1505 Diesel 60 Amp Alter.	P1000-8223-003
Drain Valve - Kubota 1505	P10009328
Throttle Cable- Kubota 1505	M10009021
Eaton 420 Pump	P10009199
Relay- 12VDC SPST 100A	P10009211

WASH DOWN	P/N
Veejet Nozzle- H1/4VV-9508	P10002943
Washdown Sprayer	P10008710
Washdown Wand	M10008709
Lighting Wand Holder	W10007674

REPLACEMENT PARTS

Miscellaneous

PRODUCT PUMP	P/N
Pump- HL32 L/RV Product	P10004373
Key Stock 3/16x3/16	P10002018
Key Stock 1/4x1/4	P10002019
Valve- 1 1/2- 3 way Ball Valve	P10004387
Valve 1" - 3 way Ball Valve	P10004391
Chain Hub - 4016x 3/4	P1000455-002
Chain Hub - 4016x 1 Bore	P1000455-004
Chain Only 4016	P10004556
Hydraulic Motor- 5.7 CI A-2 Bolt	P10009016
2" Suction Screen	W10004337

TRAILER	P/N
Tire- Wheel Assembly 225/75R15	P10004643
Chain- Safety w/Hook 48 GR 43	P10004671
Axle- 672DUE w/Elec Brakes	P10006584
Pintle Ring	W10004075
Screw Jack	W10007212

LIGHTS	P/N
Strobe Light Beacon	P10008362
Light- 2.5" Red Clearance	P10002892
Light- 2.5" Amber Clearance	P10002893
Light- 6" Oval Stop- Tail- Turn	P10002899

MISCELLANEOUS	P/N
Compactor Plate Carrier Winch	P10002298
Break Away Switch Assembly	A10003683
Battery Box Assembly	A10003290
Shovel Platform Assembly	A10008702-002
60 Gal Fuel Tank Assembly	A10008792
Hydraulic OIL #32	P10001292
Hydraulic Cap and Screen	P10001114
Valve- 2" Ball 2 Port	P10005993
Sight Gauge	P10007361
Suction Strainer	P10008421
35 Gal Hydraulic Tank	W10008975
Valve- 1 1/2 2 way Ball	P10008125
Drain Cock Assembly	A10008922
Flex Hose 1" MNPT x FJIC x 36	P10008456-036

NHTSA

NHTSA Reporting Safety Defects

If you believe that your vehicle has a defect in which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying STEPP MANUFACTURING CO., INC..

If NHTSA receives similar complaints, it may open an investigation and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or STEPP MANUFACTURING CO., INC..

To Contact NHTSA, you may either call the Auto Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to <http://www.safercar.gov>; or Write to: NHTSA, US Department of Transportation, 1200 New Jersey Ave., S.E., Washington DC 20590. You can also obtain information about your motor vehicle safety from <http://www.safercar.gov>.



Consumer Warranty Guide



Introduction

Congratulations on your purchase of equipment built by Stepp Manufacturing for your asphalt maintenance needs. Your equipment has been designed and constructed to give you the most in performance, ease of use, and reliability. It is our desire that you will find operating the equipment both productive and profitable.

Warranty Procedures Through A Dealer

If your equipment requires repair, or needs parts for repair, please contact your area dealer. For repairs, the unit must be brought to the dealer for warranty. The dealer will require purchase date information, where the machine was purchased, and the Vehicle Identification Number (VIN) of the equipment. This information is needed so the dealer can submit a warranty claim. The dealer will repair your equipment, once warranty is approved, at no charge to you under the provisions of the warranty policy.

Warranty Procedures Direct Through The Factory *(when no servicing dealer is available in your area)*

Contact Stepp Manufacturing's Customer Service Department at (651) 674-4491.

In this situation, it may be advantageous for you to repair the machine and be reimbursed direct from the factory for warranty repairs. If you do not have the facilities, or the technicians, to perform the repair, the unit can be brought to a local repair facility. In either case, Stepp Manufacturing **MUST** be contacted and authorize the warranty repair **PRI-OR** to any work being performed. If work is done prior to authorization, the warranty will not be honored.

If parts are required for the warranty repair, contact Customer Service at Stepp Manufacturing for replacements. When warranty replacement parts are shipped to you, a Warranty Authorization Number will be issued. If asked to return the defective parts, "tag" the defective parts with the Warranty Authorization Number, then package them in the same box the new parts were shipped in. Ten (10) business days will be allowed for return of the defective parts. If the defective part is not received back at the factory within this allotted time, the warranty will not be honored.

You will be billed for all parts shipped that require returning of defective parts. However, when the defective parts are returned and evaluated, you will receive credit for the cost of the part only. Thus, it is important that all defective parts are turned to Stepp Manufacturing in the allotted ten (10) day period.

Engine Warranty Claims

When a warranty issue develops with the engine, bring the unit to the engine manufacturer nearest authorized service center for repair. Be prepared to supply them with proof of purchase information with purchase dates.

Stepp Manufacturing cannot process engine warranty claims. However, we will be happy to offer assistance in locating the nearest service center.

Equipment Owner Responsibilities

As the equipment owner, you are responsible for:

- Using the equipment in accordance with the correct operating procedures as shown in the operators manual.
- Assuring all maintenance items are completed in accordance with the operators/maintenance manuals.
- Transporting the equipment to the place where warranty repairs can be completed.
- Supplying purchase date and VIN information to establish warranty coverage.



General Warranty Statement
Stepp Manufacturing's One (1) Year Limited Warranty

Stepp Manufacturing Co., Inc. hereby warrants, to the original purchaser of new equipment, that products manufactured by Stepp Manufacturing will be free from defects in material and workmanship for a period of one (1) year from the date of purchase from Stepp Manufacturing.

Stepp Manufacturing, at its discretion, will provide for the repair or replacement of any part found, upon examination by Stepp Manufacturing, to be defective, except as noted below. Such repair or replacement shall be free of charge to the original purchaser of new equipment for a period of one (1) year from the date of purchase, except as noted below.

No warranty is extended to cover:

- Product pump wear or damage caused by foreign objects.
- Routine maintenance, cleaning, and adjustments.
- Parts or components that have been altered, misused, improperly adjusted, or improperly maintained.
- Transportation to and from the place of warranty repair.
- Removal of materials from equipment.

The following items are covered solely by their manufacturer's warranty:

- Engines
- Hydraulic components
- Burners
- Pumps
- Axles
- Tires
- Other component parts not solely manufactured by Stepp Manufacturing

The following items are covered by a pro-rata warranty:

- Hoses that carry heated materials
- Heating elements for material hoses and wands

Disclaimer of further warranty:

Stepp Manufacturing makes no warranty, expressed or implied, other than this warranty. The implied warranties of merchantability and fitness for a particular purpose are hereby disclaimed. Repair or replacement of products or parts proving to be defective in material or workmanship shall be the exclusive remedy for breach of this warranty.

Stepp Manufacturing shall not be liable for incidental or consequential damages. Including, but not limited to, damages for inconvenience, rental or purchase of replacement equipment, loss of profits, or other loss resulting from breach of this warranty.

Stepp Manufacturing reserves the right to incorporate any changes in design into its products without obligation to make such changes on products previously manufactured.



**Twelve (12) Month Pro-Rata Limited Warranty
Heated Asphalt Hose and Heating Elements**

Effective for Equipment Delivered After 5/1/2012

Stepp Manufacturing Co., Inc. hereby warrants to the original purchaser, on a pro-rated basis, that the heated asphalt hose and heating elements installed on NEW Stepp Manufacturing’s equipment shall be free from defects in material and workmanship for period of twelve (12) months for the heated asphalt hose and six (6) months for the heating element.

In the event that a heated asphalt material hose or a heating element fails under normal use during the warranty period, Stepp Manufacturing will supply a replacement heated asphalt hose or heating element, along with one-half (0.5) hour for installation labor on a pro-rated adjustment basis.

- If the failure occurs under normal use within the first three (3) months from date of purchase, Stepp Manufacturing will supply a replacement, and provide for one-half (0.5) hour installation labor at no charge to the customer.
- If the failure occurs under normal use within the fourth (4th) through twelfth (12th) months, Stepp Manufacturing will supply a replacement, and provide for one-half (0.5) hour installation labor on a pro-rata basis.

The pro-rated adjustment is based on the total number of months elapsed since the purchase date of the new equipment from Stepp Manufacturing. This rate is then applied to the one-half (0.5) hour labor rate and the current suggested retail price of the proper replacement heated asphalt hose or heating element supplied by Stepp Manufacturing. This is the amount the customer will have to pay. Freight will not be included in the reimbursement. If a new heated asphalt hose or heating element is needed prior to warranty inspection, you will be billed for all parts shipped that require returning of defective parts. However, when the defective parts are returned and evaluated, you will receive credit for the cost of the part only. **Thus, it is important that all defective parts are turned in to Stepp Manufacturing in the allotted ten (10) day period, or warranty will be denied.**

In no case will the warranty coverage extend beyond the six (6) month period for the heating element or the twelve (12) month period for the heated asphalt hose, from the original purchase date of the new equipment from Stepp Manufacturing. *Physical damage is not covered by this warranty.* Physical damage may include, but is not limited to:

- Broken heating element (typically caused by repeated bending to less than a one (1) foot radius).
- Heated asphalt hoses burnt from the inside (typically caused by operating the heating element in an empty hose).
- External cuts or abrasions on the heated asphalt hose (typically caused by dragging on the ground).

The chart below shows the pro-rated amount, by percentage, that will be allowed by warranty, pending examination of the heated asphalt hose or heating element.

Heated Asphalt Hose		
Failure Date	Warranty’s Responsibility	Customer’s Responsibility
0-3 Months <i>0-90 Days</i>	100%	0%
3-6 Months <i>91-180 Days</i>	70%	30%
6-7 Months <i>181-211 Days</i>	60%	40%
7-8 Months <i>212-242 Days</i>	50%	50%
8-9 Months <i>243-273 Days</i>	40%	60%
9-10 Months <i>274-304 Days</i>	30%	70%
10-11 Months <i>305-335 Days</i>	20%	80%
11-12 Months <i>336-365 Days</i>	10%	90%
After 12 Months	0%	100%

Heating Element		
Failure Date	Warranty’s Responsibility	Customer’s Responsibility
0-3 Months <i>0-90 Days</i>	100%	0%
3-4 Months <i>91-121 Days</i>	60%	40%
4-5 Months <i>122-152 Days</i>	40%	60%
5-6 Months <i>153-180 Days</i>	20%	80%
After 6 Months	0%	100%



Warranty Claim Authorization Number: _____
 Call Customer Service at 651-674-4491 to obtain prior approval or warranty will be denied.
 Date of Authorization Request _____

Equipment Owner		Warranty to be Performed by	
Customer Name		Company Name	
Street Address		Address	
City/State/Zip		City/State/Zip	
Equipment Model #		Contact Name	
Equipment VIN		Contact Phone #	
Hour Meter Read			
Purchase Date		Date of Malfunction	
Dealer Purchased Form		Date of Repair	

Warranty Authorization		Signature for Authorization	
Date of Malfunction		X	
Date of Repair			

Symptoms / Diagnostics / Action		
Symptoms	Diagnostics	Action
<i>Describe the symptoms in detail, be as specific as possible. Ex: Burner ignites and runs for 35 seconds, then goes out.</i>	<i>Describe issues found, be as specific as possible. Ex: Part failed due to loose connection, resulting in misalignment and premature wear.</i>	<i>Describe action taken, be as specific as possible. Ex: Removed damaged section of wire harness, soldered new leads in place, and insulated splices w/ heat shrink tubing.</i>

Parts and Labor				
Labor Time to Correct Problem (reimbursed at \$55/hour)		Parts Used to Correct Problem		
Labor Time (in hours)	Repair Made	Part Number	Description	Qty

Parts Return

All parts returned must be tagged with the warranty authorization number and a copy of this claim. Retain all parts until credit is received from the factory. When requested, return the parts, along with this claim, to:

Stepp Manufacturing Co., Inc.
Attn: Warranty Department
12325 River Road
North Branch MN 55056


***Note:** If defective parts are not returned within 10 days, or this warranty claim does not accompany the returned parts, the claim will be denied.

Office Use Only				
Date Claim/Parts Received?		Is this a warrantable claim?	Yes	No
Claim Reviewed By:		Original Invoice # for Parts		
Date of Review:				

SCHEMATICS


REVISIONS		
REV.	DESCRIPTION	DATE
001	PREPARED FOR PROTOTYPE	1/10/2011
002		

NOTE: FOR FITTINGS, SEE RESPECTIVE ASSEMBLIES



STEPP MFG		STEPP MFG CO., INC.	
ADDRESS	1000 STEPP DRIVE	ADDRESS	1000 STEPP DRIVE
CITY	WYOMING, WY 82001	CITY	WYOMING, WY 82001
PHONE	307-333-1111	PHONE	307-333-1111
FAX	307-333-1112	FAX	307-333-1112
EMAIL	SALES@STEPPMFG.COM	EMAIL	SALES@STEPPMFG.COM
WEBSITE	WWW.STEPPMFG.COM	WEBSITE	WWW.STEPPMFG.COM
SCALE	1:18	SCALE	1:18
DATE	3/10/2011	DATE	3/10/2011
DESIGNED BY	SEE RESPECTIVE DRAWINGS	DESIGNED BY	SEE RESPECTIVE DRAWINGS

REV.	DESCRIPTION	DATE	APPV
------	-------------	------	------



- NOTE:
- A1 - A 1000W 303-XXX - HOT OIL BURNER TO C8
 - A2 - A 1000W 303-XXX - REAR BURNER TO C9
 - A3 - A 1000W 303-XXX - FRONT BURNER TO C9
 - A4 - A 1000W 307-XXX - RTD EXTENSION
 - A5 - A 1000W 301 - POWER CONTROL HARNESS
 - A6 - A 1000W 301 - HOT OIL MOTOR HARNESS
 - A7 - A 1000W 306 - EMERGENCY STOP TO ENGINE
 - A8 - A 1000W 304 - HYDRAULIC VALVE HARNESS
 - A9 - A 1000W 303-XXX - BOOM HEAT CTR. HARNESS
 - A10 - A 1000W 303-XXX - HEATED ROOM HARNESS
 - A11 - A 1000W 303-XXX - STROBE LIGHT HARNESS
 - A12 - A 1000W 313-XXX - WASHDOWN HARNESS

DASHED LINES
REPRESENT OPTIONS

STEPP MFG 17555 STATE ST. JAL STEPP MFG. DIV. 2000 W. 10TH ST. JAL JALISCO, CALIF. 95320		SCALE: 1:3 TYP. 1:1000VAC/3P 50 HERTZ/60 HERTZ	
DRAWING NO. 1000W 303-XXX REV. 1 DATE 10/1/80 BY JAL	DRAWING NO. 1000W 303-XXX REV. 1 DATE 10/1/80 BY JAL	DRAWING NO. 1000W 303-XXX REV. 1 DATE 10/1/80 BY JAL	DRAWING NO. 1000W 303-XXX REV. 1 DATE 10/1/80 BY JAL

HYDRAULIC OIL MSDS

MATERIAL SAFETY DATA SHEET

SECTION 1	PRODUCT AND COMPANY IDENTIFICATION
------------------	---

PRODUCT

Product Name: UNIVIS N 32
Product Description: Base Oil and Additives
Product Code: 8259
Intended Use: Hydraulic fluid

COMPANY IDENTIFICATION

Supplier: Canada Imperial Oil Limited, An Affiliate of Exxon Mobil Corporation
P.O. Box 4029, Station A
Calgary, ALBERTA. T2P 3M9 Canada

24 Hour Health Emergency 519-339-2145
Transportation Emergency Phone 519-339-2145
Supplier General Contact 1-800-567-3776

SECTION 2	COMPOSITION / INFORMATION ON INGREDIENTS
------------------	---

Reportable Hazardous Substance(s) or Complex Substance(s)

Name	CAS#	Concentration*
HYDROTREATED LIGHT NAPHTHENIC DISTILLATE (PETROLEUM)	64742-53-6	20 - 30%

* All concentrations are percent by weight unless material is a gas. Gas concentrations are in percent by volume.

SECTION 3	HAZARDS IDENTIFICATION
------------------	-------------------------------

This material is not considered to be hazardous according to regulatory guidelines (see (M)SDS Section 15).

POTENTIAL HEALTH EFFECTS

Low order of toxicity. Excessive exposure may result in eye, skin, or respiratory irritation. High-pressure injection under skin may cause serious damage.

NFPA Hazard ID: Health: 0 Flammability: 1 Reactivity: 0
HMIS Hazard ID: Health: 0 Flammability: 1 Reactivity: 0

NOTE: This material should not be used for any other purpose than the intended use in Section 1 without expert advice. Health studies have shown that chemical exposure may cause potential human health risks which may vary from person to person.

SECTION 4	FIRST AID MEASURES
------------------	---------------------------

INHALATION

Remove from further exposure. For those providing assistance, avoid exposure to yourself or others. Use adequate respiratory protection. If respiratory irritation, dizziness, nausea, or unconsciousness occurs, seek immediate medical assistance. If breathing has stopped, assist ventilation with a mechanical device or use mouth-to-mouth resuscitation.

SKIN CONTACT

Wash contact areas with soap and water. If product is injected into or under the skin, or into any part of the body, regardless of the appearance of the wound or its size, the individual should be evaluated immediately by a physician as a surgical emergency. Even though initial symptoms from high pressure injection may be minimal or absent, early surgical treatment within the first few hours may significantly reduce the ultimate extent of injury.

EYE CONTACT

Flush thoroughly with water. If irritation occurs, get medical assistance.

INGESTION

First aid is normally not required. Seek medical attention if discomfort occurs.

SECTION 5	FIRE FIGHTING MEASURES
------------------	-------------------------------

EXTINGUISHING MEDIA

Appropriate Extinguishing Media: Use water fog, foam, dry chemical or carbon dioxide (CO₂) to extinguish flames.

Inappropriate Extinguishing Media: Straight Streams of Water

FIRE FIGHTING

Fire Fighting Instructions: Evacuate area. Prevent runoff from fire control or dilution from entering streams, sewers, or drinking water supply. Firefighters should use standard protective equipment and in enclosed spaces, self-contained breathing apparatus (SCBA). Use water spray to cool fire exposed surfaces and to protect personnel.

Unusual Fire Hazards: Pressurized mists may form a flammable mixture.

Hazardous Combustion Products: Smoke, Fume, Sulfur oxides, Aldehydes, Oxides of carbon, Incomplete combustion products

FLAMMABILITY PROPERTIES

Flash Point [Method]: 165C (329F) [ASTM D-93]

Flammable Limits (Approximate volume % in air): LEL: 0.9 UEL: 7.0

Auto ignition Temperature: N/D

SECTION 6**ACCIDENTAL RELEASE MEASURES****NOTIFICATION PROCEDURES**

In the event of a spill or accidental release, notify relevant authorities in accordance with all applicable regulations. U.S. regulations require reporting releases of this material to the environment which exceed the reportable quantity or oil spills which could reach any waterway including intermittent dry creeks. The National Response Center can be reached at (800)424-8802.

SPILL MANAGEMENT

Land Spill: Stop leak if you can do it without risk. Recover by pumping or with suitable absorbent.

Water Spill: Stop leak if you can do it without risk. Confine the spill immediately with booms. Warn other shipping. Remove from the surface by skimming or with suitable absorbents. Seek the advice of a specialist before using dispersants.

Water spill and land spill recommendations are based on the most likely spill scenario for this material; however, geographic conditions, wind, temperature, (and in the case of a water spill) wave and current direction and speed may greatly influence the appropriate action to be taken. For this reason, local experts should be consulted. Note: Local regulations may prescribe or limit action to be taken.

ENVIRONMENTAL PRECAUTIONS

Large Spills: Dike far ahead of liquid spill for later recovery and disposal. Prevent entry into waterways, sewers, basements or confined areas.

SECTION 7**HANDLING AND STORAGE****HANDLING**

Prevent small spills and leakage to avoid slip hazard.

Static Accumulator: This material is a static accumulator.

STORAGE

Do not store in open or unlabelled containers.

SECTION 8**EXPOSURE CONTROLS / PERSONAL PROTECTION**

Exposure limits/standards for materials that can be formed when handling this product: When mists / aerosols can occur, the following are recommended: 5 mg/m³ - ACGIH TLV, 10 mg/m³ - ACGIH STEL, 5 mg/m³ - OSHA PEL.

NOTE: Limits/standards shown for guidance only. Follow applicable regulations.

ENGINEERING CONTROLS

The level of protection and types of controls necessary will vary depending upon potential exposure conditions. Control measures to consider:

No special requirements under ordinary conditions of use and with adequate ventilation.

PERSONAL PROTECTION

Personal protective equipment selections vary based on potential exposure conditions such as applications, handling practices, concentration and ventilation. Information on the selection of protective equipment for use with this material, as provided below, is based upon intended, normal usage.

Respiratory Protection: If engineering controls do not maintain airborne contaminant concentrations at a level which is adequate to protect worker health, an approved respirator may be appropriate. Respirator selection, use, and maintenance must be in accordance with regulatory requirements, if applicable. Types of respirators to be considered for this material include:

No special requirements under ordinary conditions of use and with adequate ventilation. For high airborne concentrations, use an approved supplied-air respirator, operated in positive pressure mode. Supplied air respirators with an escape bottle may be appropriate when oxygen levels are inadequate, gas/vapor warning properties are poor, or if air purifying filter capacity/rating may be exceeded.

Hand Protection: Any specific glove information provided is based on published literature and glove manufacturer data. Work conditions can greatly effect glove durability; inspect and replace worn or damaged gloves. The types of gloves to be considered for this material include:

No protection is ordinarily required under normal conditions of use.

Eye Protection: If contact is likely, safety glasses with side shields are recommended.

Skin and Body Protection: Any specific clothing information provided is based on published literature or manufacturer data. The types of clothing to be considered for this material include:

No skin protection is ordinarily required under normal conditions of use. In accordance with good industrial hygiene practices, precautions should be taken to avoid skin contact.

Specific Hygiene Measures: Always observe good personal hygiene measures, such as washing after handling the material and before eating, drinking, and/or smoking. Routinely wash work clothing and protective equipment to remove contaminants. Discard contaminated clothing and footwear that cannot be cleaned. Practice good housekeeping.

ENVIRONMENTAL CONTROLS

See Sections 6, 7, 12, 13.

SECTION 9	PHYSICAL AND CHEMICAL PROPERTIES
------------------	---

Typical physical and chemical properties are given below. Consult the Supplier in Section 1 for additional data.

GENERAL INFORMATION

Physical State: Liquid

Color: Yellow

Odor: Characteristic

Odor Threshold: N/D

IMPORTANT HEALTH, SAFETY, AND ENVIRONMENTAL INFORMATION

Relative Density (at 15 C): 0.87

Flash Point [Method]: 165C (329F) [ASTM D-93]

Flammable Limits (Approximate volume % in air): LEL: 0.9 UEL: 7.0

Auto ignition Temperature: N/D

Boiling Point / Range: 229C (444F) - 512C (954F)

Vapor Density (Air = 1): N/D

Vapor Pressure: [N/D at 40 °C] | < 1 kPa (7.5 mm Hg) at 38C

Evaporation Rate (n-butyl acetate = 1): < 0.1

pH: N/A

Log Pow (n-Octanol/Water Partition Coefficient): > 3.5

Solubility in Water: Negligible

Viscosity: 32 cSt (32 mm²/sec) at 40 C

Oxidizing Properties: See Sections 3, 15, 16.

OTHER INFORMATION**Freezing Point:** N/D**Melting Point:** N/A**Pour Point:** -48°C (-54°F)**DMSO Extract (mineral oil only), IP-346:** < 3 %wt

SECTION 10	STABILITY AND REACTIVITY
-------------------	---------------------------------

STABILITY: Material is stable under normal conditions.**CONDITIONS TO AVOID:** Excessive heat. High energy sources of ignition.**MATERIALS TO AVOID:** Strong oxidizers**HAZARDOUS DECOMPOSITION PRODUCTS:** Material does not decompose at ambient temperatures.**HAZARDOUS POLYMERIZATION:** Will not occur.

SECTION 11	TOXICOLOGICAL INFORMATION
-------------------	----------------------------------

ACUTE TOXICITY

<u>Route of Exposure</u>	<u>Conclusion / Remarks</u>
Inhalation	
Toxicity (Rat): LC50 > 5000 mg/m ³	Minimally Toxic. Based on assessment of the components.
Irritation: No end point data.	Negligible hazard at ambient/normal handling temperatures. Based on assessment of the components.
Ingestion	
Toxicity (Rat): LD50 > 2000 mg/kg	Minimally Toxic. Based on test data for structurally similar materials.
Skin	
Toxicity (Rabbit): LD50 > 2000 mg/kg	Minimally Toxic. Based on test data for structurally similar materials.
Irritation (Rabbit): Data available.	Negligible irritation to skin at ambient temperatures. Based on assessment of the components.
Eye	
Irritation (Rabbit): Data available.	May cause mild, short-lasting discomfort to eyes. Based on assessment of the components.

CHRONIC/OTHER EFFECTS**Contains:**

Base oil severely refined: Not carcinogenic in animal studies. Representative material passes IP-346, Modified Ames test, and/or other screening tests. Dermal and inhalation studies showed minimal effects; lung non-specific infiltration of immune cells, oil deposition and minimal granuloma formation. Not sensitizing in test animals.

Additional information is available by request.

The following ingredients are cited on the lists below: None.

--REGULATORY LISTS SEARCHED--

1 = NTP CARC

3 = IARC 1

5 = IARC 2B

2 = NTP SUS

4 = IARC 2A

6 = OSHA CARC

SECTION 12	ECOLOGICAL INFORMATION
-------------------	-------------------------------

The information given is based on data available for the material, the components of the material, and similar materials.

ECOTOXICITY

Material -- Not expected to be harmful to aquatic organisms.

MOBILITY

Base oil component -- Low solubility and floats and is expected to migrate from water to the land. Expected to partition to sediment and wastewater solids.

PERSISTENCE AND DEGRADABILITY

Biodegradation:

Base oil component -- Expected to be inherently biodegradable

BIOACCUMULATION POTENTIAL

Base oil component -- Has the potential to bioaccumulate, however metabolism or physical properties may reduce the bioconcentration or limit bioavailability.

SECTION 13	DISPOSAL CONSIDERATIONS
-------------------	--------------------------------

Disposal recommendations based on material as supplied. Disposal must be in accordance with current applicable laws and regulations, and material characteristics at time of disposal.

DISPOSAL RECOMMENDATIONS

Product is suitable for burning in an enclosed controlled burner for fuel value or disposal by supervised incineration at very high temperatures to prevent formation of undesirable combustion products.

REGULATORY DISPOSAL INFORMATION

RCRA Information: The unused product, in our opinion, is not specifically listed by the EPA as a hazardous waste (40 CFR, Part 261D), nor is it formulated to contain materials which are listed as hazardous wastes. It does not exhibit the hazardous characteristics of ignitability, corrosivity or reactivity and is not formulated with contaminants as determined by the Toxicity Characteristic Leaching Procedure (TCLP). However, used product may be regulated.

Empty Container Warning PRECAUTIONARY LABEL TEXT: Empty containers may retain residue and can be dangerous. DO NOT PRESSURIZE, CUT, WELD, BRAZE, SOLDER, DRILL, GRIND OR EXPOSE SUCH CONTAINERS TO HEAT, FLAME, SPARKS, STATIC ELECTRICITY, OR OTHER SOURCES OF IGNITION; THEY MAY EXPLODE AND CAUSE INJURY OR DEATH. Do not attempt to refill or clean container since residue is difficult to remove. Empty drums should be completely drained, properly bunged and promptly returned to a drum reconditioner. All containers should be disposed of in an environmentally safe manner and in accordance with governmental regulations.

SECTION 14	TRANSPORT INFORMATION
-------------------	------------------------------

LAND (DOT) : Not Regulated for Land Transport

LAND (TDG) : Not Regulated for Land Transport

SEA (IMDG) : Not Regulated for Sea Transport according to IMDG-Code

AIR (IATA) : Not Regulated for Air Transport

SECTION 15	REGULATORY INFORMATION
-------------------	-------------------------------

OSHA HAZARD COMMUNICATION STANDARD: When used for its intended purposes, this material is not classified as hazardous in accordance with OSHA 29 CFR 1910.1200.

NATIONAL CHEMICAL INVENTORY LISTING: DSL, TSCA

EPCRA: This material contains no extremely hazardous substances.

SARA (311/312) REPORTABLE HAZARD CATEGORIES: Delayed Health.

SARA (313) TOXIC RELEASE INVENTORY: This material contains no chemicals subject to the supplier notification requirements of the SARA 313 Toxic Release Program.

The Following Ingredients are Cited on the Lists Below:*

Chemical Name	CAS Number	List Citations
HYDROTREATED LIGHT NAPHTHENIC DISTILLATE (PETROLEUM)	64742-53-6	13, 17, 18
PHOSPHORODITHOIC ACID, O,O-DI C1-14-ALKYL ESTERS, ZINC SALTS (2:1) (ZDDP)	68649-42-3	15

--REGULATORY LISTS SEARCHED--

- | | | | |
|---------------|------------------|-------------------|-------------|
| 1 = ACGIH ALL | 6 = TSCA 5a2 | 11 = CA P65 REPRO | 16 = MN RTK |
| 2 = ACGIH A1 | 7 = TSCA 5e | 12 = CA RTK | 17 = NJ RTK |
| 3 = ACGIH A2 | 8 = TSCA 6 | 13 = IL RTK | 18 = PA RTK |
| 4 = OSHA Z | 9 = TSCA 12b | 14 = LA RTK | 19 = RI RTK |
| 5 = TSCA 4 | 10 = CA P65 CARC | 15 = MI 293 | |

Code key: CARC=Carcinogen; REPRO=Reproductive

* EPA recently added new chemical substances to its TSCA Section 4 test rules. Please contact the supplier to confirm whether the ingredients in this product currently appear on a TSCA 4 or TSCA 12b list.

N/D = Not determined, N/A = Not applicable

THIS SAFETY DATA SHEET CONTAINS THE FOLLOWING REVISIONS:

No revision information is available.

The information and recommendations contained herein are, to the best of Exxon Mobil's knowledge and belief, accurate and reliable as of the date issued. You can contact Exxon Mobil to insure that this document is the most current available from Exxon Mobil. The information and recommendations are offered for the user's consideration and examination. It is the user's responsibility to satisfy itself that the product is suitable for the intended use. If buyer repackages this product, it is the user's responsibility to insure proper health, safety and other necessary information is included with and/or on the container. Appropriate warnings and safe-handling procedures should be provided to handlers and users. Alteration of this document is strictly prohibited. Except to the extent required by law, re-publication or retransmission of this document, in whole or in part, is not permitted. The term, "Exxon Mobil" is used for convenience, and may include any one or more of Exxon Mobil Chemical Company, Exxon Mobil Corporation, or any affiliates in which they directly or indirectly hold any interest.

Internal Use Only

MHC: 0, 0, 0, 0, 0, 0

PPEC: A

DGN: 5007202 (1012936)

Copyright 2002 Exxon Mobil Corporation, All rights reserved